



International Electric Medium Duty Truck (eMV™) Electrical Systems Integration Guide

**Copyright International Motors LLC 2025 All Rights Reserved**

## Table of Contents

<b>1. Revision Summary Table</b> .....	<b>5</b>
<b>2. Foreword:</b> .....	<b>6</b>
<b>3. Vehicle Architectures:</b> .....	<b>10</b>
3.1. Multiplexing Architecture: .....	10
3.2. Vehicle Multiplex Architecture .....	11
3.3. Vehicle Power Distribution Architecture: .....	12
<b>4. Body Control Module (BCM)</b> .....	<b>13</b>
4.1. Body Control Module Gen IV: .....	13
4.2. Body Control Module “Real-time Clock” Internal Power Source: .....	14
4.3. Body Control Module Gen IV Connector Composite: .....	16
4.4. Body Controller J1 Connector 1603 I/O & Part Number Detail: .....	17
4.5. Body Controller J2 Connector 1604 I/O & Part Number Detail: .....	18
4.6. Body Controller J3 Connector 1600 I/O & Part Number Detail: .....	19
4.7. Body Controller J4 Connector 1601 I/O & Part Number Detail: .....	20
4.8. Body Controller J5 Connector 1602 I/O & Part Number Detail: .....	21
4.9. Body Controller J6 Connector 1605 I/O & Part Number Detail: .....	22
4.10. Body Controller J7 Connector 1606 I/O & Part Number Detail: .....	23
<b>5. Multiplex Switch-Packs (Center Panel Mounted)</b> .....	<b>24</b>
5.1. Multiplex Switch-Pack Housing: .....	24
5.2. Multiplex Switch-Pack Cover .....	24
5.3. Multiplex Switch-Pack Storage Bin: .....	24
5.4. Multiplex Switch-Pack Actuators, Blanks (plugs) and Indicators: .....	25
5.5. Multiplex Switch-Pack Warning Lights: .....	35
5.6. Switch Label Applique Sheet #1 (Utility/Wrecker): .....	37
5.7. Switch Label Applique Sheet #2 (Fire): .....	38
5.8. Switch Label Applique Sheet #3 (Limo/Bus/Propane): .....	39
5.9. Switch Label Applique Sheet #4 (Airport Refueler/Concrete Mixer): .....	40
5.10. Switch Label Applique Sheet #5 (Plow/Dump): .....	41
5.11. Switch Label Applique Sheet #6 (Tanker) .....	42
5.12. Switch Label Applique Sheet #7 (Ambulance/Fire): .....	43
5.13. Switch Label Applique Sheet #8 (Adv Fire/Ambulance): .....	44
5.14. Switch Label Applique Sheet #9 (On/Off/Blank): .....	45
5.15. Switch Label Applique Sheet #10 (Miscellaneous): .....	46
<b>6. Customized Steering Wheel Switches</b> .....	<b>47</b>
<b>7. Lighting Control Module:</b> .....	<b>52</b>
7.1. Lighting Control Module Housing: .....	52
7.2. Lighting Control Module and Associated Parts: .....	52
<b>8. Remote Power Modules:</b> .....	<b>53</b>
8.1. Remote Power Module Composite View .....	53
8.2. Remote Power Module CAN Pass-through Connector .....	54
8.3. Body Equipment Power Output Connector .....	55
8.4. Body Equipment Signal Input Connector .....	56
8.5. Remote Power Module Address Jumper Locations .....	57
8.6. Remote Power Module Power Connections .....	57
<b>9. Instrument Panel</b> .....	<b>58</b>
<b>10. Air Conditioning</b> .....	<b>59</b>
<b>11. 12 Volt System</b> .....	<b>60</b>
11.1. 12-VOLT BATTERY CHARGING .....	60
11.2. 08RMH: BATTERY DISCONNECT SWITCH Cole-Hersee 75920-06} 300 Amp, Disconnects Charging Circuits, Locks with Padlock, Battery Box Mounted. ....	62
<b>12. Body Builder Wiring, for Stop/Turn/Tail Lights/ Through Power:</b> .....	<b>63</b>

12.1. 08HAA: BODY BUILDER WIRING To EOF, With Stop, Tail, Turn, and Marker Lights Circuits, Ignition (IGN)-Controlled Auxiliary Feed and Ground (GND), Less Trailer Socket. ....	63
<b>13. CB and 2-Way Radio Accommodation Packages .....</b>	<b>67</b>
13.1. 08RNC: CB RADIO Accommodation Package, Header Mounted, Feeds from Accessory Side of Ignition Switch, Includes Power Source, Two Antennas and Antenna Bases with Wiring on Both Side Mirror .....	67
<b>14. Fog Light Package .....</b>	<b>69</b>
14.1. 08XJH: FOG LIGHTS (2) Clear Lens, LED, Rectangular, with White Light Source .....	69
<b>15. Gauges and Fault Code Display .....</b>	<b>71</b>
15.1. 16HKA IP CLUSTER DISPLAY Omit Display of Diagnostic Trouble Codes in Instrument Cluster and Disable Blink Codes, Requires Service Tool to Retrieve and View Fault Code.....	71
<b>16. In Cab Battery Feed and USB Power Source .....</b>	<b>71</b>
16.1. 08XPK: POWER SOURCE, ADDITIONAL Auxiliary Power Outlet (APO) with USB-A Port and USB-C Port, Located in the Instrument Panel. ....	71
16.2. 08XPL: POWER SOURCE, ADDITIONAL Auxiliary Power Outlet (APO) with Two USB-A Ports and Two USB-C Ports, Located in the Instrument Panel. ....	72
16.3. 08XPN: USB PORT One USB-A Port and one USB-C Port, Located in the Instrument Panel. ....	73
16.4. 08XPP: USB PORT Two USB-A Ports and Two USB-C Ports, Located in the Instrument Panel.....	74
<b>17. Liftgate Accommodation Package .....</b>	<b>76</b>
17.1. 08VBA: POWER SOURCE, SPECIAL for Customer Installed Lift Gate; 200 Amp Max, Includes 00ga. Power Cable to End of Frame, Optional Power (PDM) for Power Source, Latched Switch on Instrument Panel, with a Time Out Feature, Battery Discharge Protection, Controlling a Mag Switch Which Provides Power. ....	76
<b>18. Power Window, Locks, Remote Keyless Entry.....</b>	<b>80</b>
18.1. 16VDZ: KEYLESS ENTRY SYSTEM REMOTE with Panic and Auxiliary Work Light Function, Includes Two Key Fobs (Transmitters). ....	80
18.2. 16WJU: WINDOW, POWER (2-Door) and Power Locks, Left and Right Doors. ....	84
18.3. 16WKZ: KEYLESS ENTRY SYSTEM REMOTE with Panic and Auxiliary Buttons, Includes One Key Fob (Transmitter). ....	87
<b>19. Productivity Features .....</b>	<b>90</b>
19.1. 08WXB: HEADLIGHT WARNING BUZZER Sounds When Head Light Switch is on, and Ignition Switch is in "Off" Position. ....	90
19.2. 08WXD: ALARM, PARKING BRAKE Electric Horn Sounds in Repetitive Manner when Vehicle Park Brake is "NOT" Set, With Ignition (IGN) "OFF" and any Door Open. ....	91
19.3. 16HCH: SEATBELT WARNING LIGHT IND. Mounted in Dash, Will Flash when Park Brake is Disengaged and Driver Seatbelt Unfastened, Audible Alarm to Remind Driver to Fasten Seatbelt .....	93
<b>20. Standard electrical Offerings.....</b>	<b>93</b>
20.1. 08WRB: HEADLIGHTS ON W/WIPERS Headlights Will Automatically Turn on if Windshield Wipers are turned on. There are two functions, Lights on With Wipers (LOWW) and Day Time Running Lights (DTRL), available with this sales code. ....	93
<b>21. Work light Outside Cab Features.....</b>	<b>94</b>
21.1. 08WMA: SWITCH, TOGGLE, FOR WORK LIGHT Lighted; on Instrument Panel and Wiring Effects for Customer Furnished Back of Cab Light. ....	94
21.2. 08WTT: SWITCH, TOGGLE, FOR WORK LIGHT Lighted; on Instrument Panel and Wiring Effects for Customer Furnished End of Frame Light.....	99
<b>22. Body Builder Integration Harnesses .....</b>	<b>102</b>
22.1. 08XMB: WIRING (1)TMC RP1226 BEHIND CTR CONSOLE CONNECTOR, DASH, CENTER PANEL Cab Wiring for TMC RP1226 Vehicle Accessory Connector; Includes 14-pin Connector with Switched Power, Battery Power, Ignition Power, Ground & Body 250K Datalink, Connector Located Behind Instrument Panel Center Console.....	102
22.2. 08XMZ: WIRING (2)TMC RP1226 BEHIND CTR CONSOLECONNECTOR, DASH, CENTER PANEL Cab Wiring for (2) TMC RP1226 Vehicle Accessory Connectors; Includes (2) 14-pin Connectors with	

Switched Power, Battery Power, Ignition Power, Ground & Body 250K Datalink, Connector Located Behind Instrument Panel Center Console.....	105
22.3. 08XNA, CENTER PANEL Cab Wiring for (3) TMC RP1226 Vehicle Accessory Connectors; Includes (3) 14-pin Connectors with Switched Power, Battery Power, Ignition Power, Ground & Body 250K Datalink, Connector Located Behind Instrument Panel Center Console.....	109
<b>23. Power Features using Remote Power Modules.....</b>	<b>112</b>
23.1. 60AAG: BDY INTG, REMOTE POWER MODULE Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs, Max 20 amp per Channel, Max 80 amp Total; Includes 1 Switch Pack with Latched Switches.....	112
23.2. 60AAH: BDY INTG, REMOTE POWER MODULE (2) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 2 Switch Packs with Latched Switches.....	117
23.3. 60AAJ: DY INTG, REMOTE POWER MODULE (3) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 3 switch Packs with Latched Switches.....	123
23.4. 60AAP: BDY INTG, REMOTE POWER MODULE (3) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 2 Modules with Switch Packs Containing 6 Latched Switches, 1 Module with Hardware Only.....	130
<b>24. ePTO .....</b>	<b>137</b>
<b>08PAA: HIGH VOLTAGE POWER ACCESSORY 40kW Electronic Power Take Off, with SAE B Pump Flange, Mounted Left Side Under Cab .....</b>	<b>137</b>
<b>25. ePower .....</b>	<b>145</b>
25.4. ePower LV Hardware Interface Integration .....	148
25.4.1. LV Voltage Range .....	148
25.5. ePower Electrical Interface Integration .....	148
25.5.1. LV Connector .....	148
25.5.2. LV Fuse for VBATT Connection .....	149
25.5.3. LV Fusing.....	150
25.5.4. ePower Enable .....	150
25.5.5. CAN System Diagram .....	150
25.5.6. High Voltage Range.....	150
25.5.7. HVDM Connection.....	150
25.5.8. HV Connector Plugs.....	151
25.5.9. HV Connector.....	151
25.5.10. Mating Keyed Connectors F (Plug/Mating connector for HV Harness).....	151
25.5.11. HV Cable.....	152
The wire selection based on the plugs as defined in section 25.5.8.....	152
25.5.12. HVDM Fuse .....	154
25.5.13. HVDM Location.....	154
25.5.14. HV Fuse.....	154
25.5.15. HVIL .....	155
25.1. System Active Discharge .....	155
25.2. Internal Contactor.....	155
25.3. System After-Run Operation.....	155
<b>26. General Electrical Section:.....</b>	<b>156</b>
26.1. "Red Gel Coat" Removal From Electrical Connections .....	156
26.2. Connecting to 12 Volt Circuits .....	161
26.3. Recommended Circuit Protection .....	161
26.4. Color Code System for International® Truck Wiring: .....	164
26.5. Electrical Components Commonly Used by Equipment Installers:.....	164
26.6. Suppression.....	165
26.7. Welding Information.....	165
26.8. Routing Guidelines.....	166
26.9. Wire Splicing and Termination - Standard Terminals and Splices:.....	167
26.10. HIGH VOLTAGE CIRCUITS (GREATER THAN 50 VOLTS) ON INTERNATIONAL TRUCKS AND BUSES:.....	175

## 1. Revision Summary Table

REVISION	DATE	SECTION	CHANGE DESCRIPTION	REASON FOR CHANGE	REVISED BY
01	9/10/2021	ALL	INITIAL DRAFT	INITIATION OF DOCUMENT	A. SCHNELLENBERGER
02	11/1/2022	ALL	MINOR CORRECTIONS		A. SCHNELLENBERGER
03	11/19/2025		Added ePTO, ePower, RPMs, more switch information and Steering wheel switch changes.	New features and information	A. SCHNELLENBERGER

## 2. Foreword:

### Warnings and Cautions

**WARNING** – To prevent personal injury and / or death, or damage to property, NEVER service a high-voltage vehicle without completing High-Voltage Safety training. Before working on vehicle, read and obey High-Voltage Safety, and Lock-Out Tag-Out safety procedures and information.

This manual provides general and specific maintenance procedures essential for reliable vehicle operation and your safety. Since many variations in procedures, tools, and service parts are involved, advice for all possible safety conditions and hazards cannot be stated.

Read all safety instructions and High-Voltage Safety procedures and information before doing any service or diagnostic procedures for the vehicle. See related application manuals for more information.

There is more information on high voltage safety and components at the end of this manual.

Disregard for Safety Instructions, Warnings, Cautions, and Notes in this manual can lead to injury, death or damage to the vehicle. Safety Terminology

Three terms are used to stress your safety and safe operation of the vehicle: Warning, Caution, and Note

Warning: A Warning describes actions necessary to prevent or eliminate conditions, hazards, and unsafe practices that can cause personal injury and / or death.

Caution: A Caution describes actions necessary to prevent or eliminate conditions that can cause damage to the vehicle.

Note: A Note describes actions necessary for correct, efficient vehicle operation.

Refer to the following manuals for more information:

International® Electric MV™ Series Operation and Maintenance Manual 0001253563 and [FIRST RESPONDER GUIDE - International ® eMV™ Series 4328810](#)

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**Ensure that all required high voltage training has been completed and all safety procedures are being followed before working on this vehicle.**

**For training:**

1. Navigate to <https://www.Internationaleducation.com>
2. Login or create an account as needed and navigate to Courses 9371 and 9374.

**WARNING** – To prevent personal injury and / or death, turn OFF the high voltage disconnect switch first and then turn OFF the 12V disconnect switch before interacting with a damaged vehicle.

**WARNING** – To prevent personal injury and / or death, ALWAYS REMEMBER the 12V disconnect switch only disables the vehicle 12-volt system, NOT the high-voltage battery system.

**WARNING** – This document contains information on a diverse set of truck chassis system and subsystem integration features which contain the potential for both simple and complex operational situations and interactions, when integrated in combination with a truck chassis and truck mounted equipment. It is the responsibility of persons performing truck chassis and, or truck mounted equipment system integration and testing to fully understand the plurality of operational outcomes and take the appropriate as well as necessary precautions to avoid property damage, personal injury, up to and including death, when performing system integration and, or testing in association with the content of this document.

Note: This manual provides information to assist with modifying the truck for individual applications. International does not recommend or approve any firm nor make any judgements on the quality of the work performed by a particular firm. Individuals who use the services of a Body Builder must satisfy themselves as to the quality of the work.

The party installing a body, any other equipment, or making any modifications to complete the vehicle for delivery and make it road-ready is responsible to see that the completed vehicle complies with all applicable certification procedures and safety standards, as may be set forth in Federal, State, and local statutes, rules and regulations.

Specifications, descriptions, and illustrative material in this literature are as accurate as known at time of publication but are subject to change without notice. Illustrations are not always to scale and may include optional equipment and accessories but may not include all standard equipment.

**IMPORTANT** - Read the following before starting the service procedure.

You must follow your company safety procedures when you service or repair equipment. Be sure to understand all procedures and instructions before you begin work on the unit. Some procedures require the use of special tools for safe and correct service. Failure to use these special tools when required can cause injury to service personnel or damage to vehicle components.

**DISCLAIMER:** INTERNATIONAL DOES NOT TAKE ANY RESPONSIBILITY FOR CUSTOMER OR BODY BUILDER WIRING.

**NOTE** - After-market installed wiring must comply with the following guidelines:

1. Sealed switches and connectors must be used for switches and connections that are exposed to the weather or to salt spray emanating from the vehicle's tires.
2. Route and clip wiring to minimize chafing and exposure to weather. Use conduit, loom, and/or tape to achieve this.
3. Fuse all power leads as close to the power source as possible. Remember fuses protect the wiring - size fuses accordingly.
4. All ground connections that will be made to the frame or body must be connected to clean bare metal. Remove all dirt, paint, grease and rust that would insulate the terminal from ground. After connecting the ground, seal the connection with a good quality grease or surface sealant to protect the connection from corrosion.
5. Spliced wires should be crimped and soldered. Use a heat shrink tube with a meltable inner wall to seal the connection. Do not expose splices to the weather.

**WARNING** – To avoid serious personal injury, possible death, or damage to the vehicle, make sure the drive selection is in neutral, parking brake is set, and the wheels are blocked before undertaking service procedures.

**WARNING** – To avoid personal injury, possible death, or damage to the vehicle when adding electrical features, disconnect batteries or use the battery disconnect switch. Reconnect batteries when installation is complete.

When disconnecting 12 Volt battery terminals, always disconnect the ground terminal first.

When reconnecting, always connect the ground terminal last.

To prevent injury to the eyes, face, limbs and body, it is imperative that lighted materials, flames or sparks be kept away from the vent openings of the battery. The gas mixture in the battery

cells, which escapes through the vents, could ignite and/or cause an explosion. This is particularly true when jumper cables are being used.

In addition, inhaling of gas produced by the normal operation of the battery could result in partial or permanent damage to the respiratory system.

Always wear eye protection when working around batteries. Do not attempt to jump-start a vehicle having a frozen battery because the battery may explode. If a frozen battery is suspected, examine all fill vents on the battery. If ice can be seen, do not attempt to start with jumper cables as long as the battery remains frozen. Thaw out the battery and recharge.

Do not check battery condition by shorting (flashing) across terminals.

Failure to observe these instructions could result in personal injury and/or damage to the vehicle.

Battery cable terminals must be clean and tight. Use hot water and common baking soda for removing terminal corrosion and for cleaning the top of the battery. Brighten the contact surface with steel wool, apply a light coat of lubricant sealing grease such as Fleetrite® 472141-C1 or equivalent and reassemble. Be sure the terminals are clamped tightly, and that the battery is clamped securely in place.

When working around the terminals and battery, use extra care to avoid shorting. A good practice is to use insulated pliers and screwdrivers.

### **3. Vehicle Architectures:**


#### **3.1. Multiplexing Architecture:**

This system uses multiplex technology to provide control and communication between major functional areas of the vehicle. Multiplexing simply means, communicating multiple pieces of information via a single twisted pair of wires (called the data link) without requiring a wire for each piece of information. This information could be gauge information such as battery voltage, or switch information that controls vehicle functions such as headlamps.

The electrical system relies on a collection of electronic circuit modules and software to perform vehicle functions instead of implementing similar features using complex wire harness designs with electromechanical relays and switches. These electronic module components are connected by data links. The data links allow the electronic components on the vehicle to communicate with one another.


The goal of multiplexing is to reduce cab harness wiring and to simplify circuits. This is accomplished by using low current data links for communicating between cab switches, the Body Controller, the Instrument Cluster, and the high voltage system Vehicle Control Unit (VCU). Other data links in the vehicle allow other electrical controllers, the BCM and the Instrument Cluster to communicate with each other.

### 3.2. Vehicle Multiplex Architecture



Vehicle Multiplex Architecture

### 3.3. Vehicle Power Distribution Architecture:



12 Volt Power Distribution Architecture

## 4. Body Control Module (BCM)


### 4.1. Body Control Module Gen IV:

At the center of the Diamond Logic® Electrical, 12-volt, System is the Body Controller (BCM). The BCM is an electronic module that provides multiple analog and switched input/output interfaces to monitor vehicle sensors and control vehicle functions through solid state switches, relay driver outputs, and serial data communications.

The BCM is located under the IP behind a kick plate to the left of the driver's left foot. All connections are located inside the cab except for the power connection that passes thru the dash panel to the under-hood compartment. The BCM receives battery power from the maxi-fuse block and Ignition (IGN) power from the IP harness.

The BCM communicates with plurality of modules over a series of differing baud rate data links in an exchange of tens of thousands of digital messages ever second. It also receives input from various sensors and hard wire inputs throughout the truck. The BCM converts these inputs, in accordance with the programmed "rules," into data to be transmitted on the datalinks. It is also the power source for circuits that feed the components, controlled by the multiplexed switches, inside and outside of the cab. The primary vehicle software programming resides in the BCM.

### Body Control Module Gen IV (Connector Header View):



#### Body Controller Gen IV Part Information:

PART NUMBER	DESCRIPTION
4044470C7	BODY CONTROL MODULE GEN IV

#### Body Control Module Part Number


#### 4.2. Body Control Module “Real-time Clock” Internal Power Source:

Note: There is an internal power cell, in the body control module, that powers the module’s internal “real-time clock”.

When there is insufficient electrical potential available, from the main chassis battery, the internal battery will maintain the internal clock. Over time this internal power cell will weaken and require replacement.


The body control module’s original internal power cell is integral to the control module and is permanently mounted on the main printed circuit board and is not intended to be a serviceable component. However, positioned next to the original internal power cell is a 2-way electrical connector which is in parallel with, but diode blocked from, the original internal power cell. A new internal power cell module assembly can be added by pinning it into the 2-way printed circuit board mounted mating connector. The replacement internal power cell module is packaged in the form of a new body control module battery cover which includes a new power cell as well as a printed circuit board mounted to the underside/interior of the new body control module battery cover. Once the new internal power cell has been connected to the printed circuit board mounted mating connector, the module assembly will replace the body control module’s original plastic battery cover.

When the body controller’s internal power cell becomes discharge a fault code can be accessed through either the gauge cluster’s diagnostic display or through International’s Diamond Logic Builder® service tool. The fault code suspect parameter number will be displayed as SPN:516824 and have the diagnostic fault code name, “RTC Battery”.



**Replacement Internal Power Cell**

**Body Controller Internal Power Cell – Uninstalled View:**




**Body Controller Gen IV Replacement Battery Part Information:**

PART NUMBER	DESCRIPTION
2514328C91	BODY CONTROL MODULE REPLACEMENT BATTERY (INTERNAL POWER CELL ASSEMBLY)


**Body Control Module Internal Battery Part Number**

### 4.3. Body Control Module Gen IV Connector Composite:




**Body Controller Gen IV Connector Composite**

#### 4.4. Body Controller J1 Connector 1603 I/O & Part Number Detail:




#### J1 Connector 1603

### 4.5. Body Controller J2 Connector 1604 I/O & Part Number Detail:




### J2 Connector 1604

## 4.6. Body Controller J3 Connector 1600 I/O & Part Number Detail:




### J3 Connector 1600

## 4.7. Body Controller J4 Connector 1601 I/O & Part Number Detail:




**J4 Connector 1601**

#### 4.8. Body Controller J5 Connector 1602 I/O & Part Number Detail:




**J5 Connector 1602**

## 4.9. Body Controller J6 Connector 1605 I/O & Part Number Detail:



**J6 Connector 1606 / 2023**

#### 4.10. Body Controller J7 Connector 1606 I/O & Part Number Detail:



**J7 Connector 1607 / 2023A**

## 5. Multiplex Switch-Packs (Center Panel Mounted)

### 5.1. Multiplex Switch-Pack Housing:




#### Parts Associated with This Device:

PART NUMBER	DESCRIPTION
4057689C2	HOUSING, SWITCH, 6 PACK DIN MULTIPLEX

**Multiplex Switch-Pack Housing Part Number**

### 5.2. Multiplex Switch-Pack Cover




#### Parts Associated with This Device:

PART NUMBER	DESCRIPTION
3765152C2	PANEL, SINGLE DIN BLANK PLATE

**Multiplex Switch-Pack Cover Part Number**




### 5.3. Multiplex Switch-Pack Storage Bin:






#### Parts Associated with This Device:

PART NUMBER	DESCRIPTION
3765149C94	BOX, ASSEMBLY, STORAGE BIN, SINGLE

**5.4. Multiplex Switch-Pack Actuators, Blanks (plugs) and Indicators:**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Graphic
Plug	3766052C1	N/A	N/A	N/A	N/A	
Work Light	4102405C1	3	Mono	Center	Yes	
Exterior Light Check	4102406C1	3	Mono	Center	Yes	
Plow Light	4102408C1	2	Bi	Up/Down	Yes	
Cab Dome & Door Lights	3766057C1	3	Tri	All	No	
Sleeper Dome & Floor Lights	3766058C1	3	Mono	Center	No	
Floor Light	3766059C1	3	Mono	Center	No	
Sleeper Temperature Control	3766061C1	3	Mono	Center	No	








**Rocker Switch Table #1**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Sleeper Fan Speed	3766062C2	3	Mono	Center	No	Increase	
						N/A	
						Decrease	
Exhaust Brake	3766063C1	2	Bi	Up/Down	Yes	On	
						Off	
Engine Brake On/Off	4102411C1	2	Bi	Up/Down	Yes	On	
						Off	
Engine Brake, Selector	3766065C1	3	Tri	All	No	Selects '3'	
						Selects '2'	
						Selects '1'	
Fan Override	4102413C1	2	Bi	Up/Down	Yes	On	
						Off	
Front Axle 4x4	4102414C1	2	Bi	Up/Down	Yes	On	
						Off	
Front Axle 6x6	4102461C1	2	Bi	Up/Down	Yes	On	
						Off	
Traction Control Off Road	4102416C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
2 Speed Axle High/Low	3766072C1	2	Bi	Up/Down	No	High	
						Low	








**Rocker Switch Table #2**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Transfer Case High/Low	4102417C1	2	Bi	Up/Down	Yes	High	
						Low	
PTO	4102418C1	2	Bi	Up/Down	Yes	On	
						Off	
Mirror Heat (Monostable)	4102419C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Mirror Heat (Bistable)	3766142C1	2	Bi	Up/Down	Yes	On	
						Off	
Auto Neutral	4102420C1	2	Bi	Up/Down	Yes	On	
						Off	
PDL Lock	4102421C1	2	Bi	Up/Down	Yes	On	
						Off	
Differential Lock	4102422C1	2	Bi	Up/Down	Yes	On	
						Off	
Forward Rear Differential Lock	3766079C1	2	Bi	Up/Down	Yes	On	
						Off	
Rear Rear Differential Lock	3766080C1	2	Bi	Up/Down	Yes	On	
						Off	
Air Suspension Dump	3766081C1	2	Bi	Up/Down	Yes	On	
						Off	







**Rocker Switch Table #3**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
5th Wheel Unlock	4102426C1	2	Mono	Down	Yes	Unlock	
						Lock	
5th Wheel Slide	4102456C1	2	Bi	Up/Down	Yes	On	
						Off	
Cruise/Throttle On/Off	3766084C1	3	Mono	Center	No	On	
						N/A	
						Off	
Cruise/Throttle Set/Resume	3766085C1	3	Mono	Center	No	Set	
						N/A	
						Resume	
Throttle On/Off	4102435C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Throttle Deceleration/Acceleration	3766102C1	3	Mono	Center	No	Decelerate	
						N/A	
						Accelerate	
Retarder On/Off	4102427C1	2	Bi	Up/Down	Yes	On	
						Off	
Retarder High/Low	3766087C1	2	Bi	Up/Down	No	High	
						Low	
Auxiliary Front Suspension	4102428C1	2	Bi	Up/Down	Yes	On	
						Off	
Engine Shutdown Override	3766089C1	2	Mono	Down	Yes	On/Off	
						N/A	

**Rocker Switch Table #4**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Transfer Case High/Neutral/Low	3766090C1	3	Tri	All	No	High	
						Neutral	
						Low	
Blank Window Rocker	4102430C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Blank Window Rocker	4102431C1	2	Bi	Up/Down	Yes	On	
						Off	
Blank Window Rocker	4102432C1	3	Tri	All	Yes	On	
						N/A	
						Off	
Blank Window Rocker	4102433C1	2	Mono	Down	Yes	On	
						Off	
Blower/Road	4102434C1	2	Bi	Up/Down	Yes	On	
						Off	
Auxiliary Transmission	3766096C1	3	Tri	All	No	Low	
						Neutral	
						High	
Humphrey Drain Valve Wet Tank	3766097C1	2	Mono	Down	No	On/Off	
						N/A	
Drain Valve - Prime Tank	3766098C1	2	Mono	Down	No	On/Off	
						N/A	
Drain Valve - Secondary Tank	3766099C1	2	Mono	Down	No	On/Off	
						N/A	


**Rocker Switch Table #5**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Lift Gate	4102436C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Lift Axle Enable	4102437C1	2	Bi	Up/Down	Yes	On	
						Off	
Lift Axle Up/Down	3766105C1	3	Mono	Center	No	Up	
						N/A	
						Down	
PTO 1	4102438C1	2	Bi	Up/Down	Yes	On	
						Off	
PTO 2	4102439C1	2	Bi	Up/Down	Yes	On	
						Off	
120V AC	4102440C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Engine Stop/Clear	4102441C1	3	Mono	Center	Yes	Stop	
						N/A	
						Clear	
0/5	3766111C1	3	Mono	Center	No	Selects '0'	
						N/A	
						Selects '5'	
1/6	3766112C1	3	Mono	Center	No	Selects '1'	
						N/A	
						Selects '6'	
2/7	3766113C1	3	Mono	Center	No	Selects '2'	
						N/A	
						Selects '7'	


**Rocker Switch Table #6**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
3/8	3766114C1	3	Mono	Center	No	Selects '3'	
						N/A	
						Selects '8'	
4/9	3766115C1	3	Mono	Center	No	Selects '4'	
						N/A	
						Selects '9'	
Economy	4102442C1	2	Mono	Down	Yes	On	
						Off	
Inhibit Regeneration (Monostable)	4102443C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Inhibit Regeneration (Bistable)	4102444C1	2	Bi	Up/Down	Yes	On	
						Off	
Parked Regeneration	4102445C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
6th Gear Disable Switch	4102446C1	2	Bi	Up/Down	Yes	On	
						Off	
Wig-Wag Headlight Enable	4102447C1	2	Bi	Up/Down	Yes	On	
						Off	
Rear Axle Load Distribution	4102448C1	2	Mono	Down	Yes	On/Off	
						N/A	
Suspension Raise	4102449C1	2 <sup>1</sup>	Bi	Up/Down	Yes	On	
						Off	

**Rocker Switch Table #7**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Transfer Case	4102450C1	2	Bi	Up/Down	Yes	On	
						Off	
Winch On/Off	4102451C1	2	Bi	Up/Down	Yes	On	
						Off	
Winch In/Out	3766130C1	3	Mono	Center	No	Out	
						N/A	
						In	
Hill Start Aid	4102452C1	2	Mono	Down	Yes	On/Off	
						N/A	
FTS Transmission Bypass Enable	4102453C1	2	Mono	Down	Yes	On/Off	
						N/A	
Heated Windshield	4102454C1	3	Mono	Center	Yes	On	
						N/A	
						Off	
Driver Position	4102455C1	2	Bi	Up/Down	Yes	Position 2	
						Position 1	
Trailer Learn	4102457C1	2	Mono	Down	Yes	On/Off	
						N/A	
Auto Start/Stop	4102459C1	3	Mono	Center	Yes	On	
						N/A	
						Off	

**Rocker Switch Table #8**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Engine Brake (ECE)	4095306C1	3	Tri	All	No	High	
Sleeper Auto Climate	4102463C1	2	Bi	Up/Down	Yes	On	
Lift Axle Up/Down 1	4072987C1	3	Mono	Center	No	On	
						N/A	
						Off	
Lift Axle Up/Down 2	4072989C1	3	Mono	Center	No	On	
						N/A	
						Off	
Lift Axle Up/Down 3	4072995C1	3	Mono	Center	No	On	
						N/A	
						Off	
Aux Trailer	4102462C1	2	Bi	Up/Down	Yes	On	
						Off	
PTO	4114975C1	3	Mono	Center	Yes	On	
						N/A	
						Off	

**Rocker Switch Table #9**

Rocker Switch Name	International P/N	Number of Positions	Switch Action	Stable Positions	Indicator	Function	Graphic
Low Speed Throttle Control (Maneuvering)	4124041C1	2	Bi	Up/Down	Yes	On	
						Off	
Drive Mode	4124040C1	2	Bi	Up/Down	Yes	On	
						Off	
Transmission PTO Split Hi/Lo	4234487C1	2	Bi	Up/Down	Yes	Hi	
						Lo	
Downhill Speed Control	4124042C1	2	Bi	Up/Down	Yes	On	
						Off	
Downhill Speed Control Res/Set	4124043C1	3	Mono	Center	No	RES +	
						N/A	
						RES -	

**Rocker Switch Table #10**

### 5.5. Multiplex Switch-Pack Warning Lights:

Warning Light	International P/N	Graphic
Blank	4108104C1	
Hill Start Assist	4084814C1	
Auto Neutral	4084815C1	
Boom Up	4084816C1	
Outrig Out	4084817C1	
Body Up	4084818C1	
Gate Open	4084819C1	
Rear Alert	4084820C1	

**Warning Light Table #1**

Warning Light	International P/N	Graphic
120V AC Power	4084821C1	
Jaw Locked	4084823C1	
Jaw Unlocked	4084824C1	
Range Inhibit	4084825C1	

**Warning Light Table #2**

**5.6. Switch Label Applique Sheet #1 (Utility/Wrecker):**

AIR COMPR	ARROW BOARD	ARROW LEFT	ARROW RIGHT	AUX PTO	BACKUP LIGHT
BEACON LIGHT	BIN LIGHT	BOOM N/STOW	BOOM STOW	BOOM UP	CARGO LIGHT
CLOSE	COMPT LIGHT	CRANE	CRANE ACTIVE	CRANE LIGHT	DECK LIGHT
DIGGER	FILTER BYPASS	FLOOD LIGHT	FRONT STROBE	GEN RUN	GROUND LIGHT
HOOK DOWN	HOOK UP	INVERTER	LOCK	LOWER WORK	MASTER
NEED REGEN	OPEN	OUTRIG N/STOW	PTO	REAR ALERT	REAR FLOOD
REAR LIGHT	REAR STROBE	SPOT LIGHT	STROBE BAR	STROBE LIGHT	SUSP DUMP
UNLOCK	UPPER WORK	WIG WAG	WINCH IN	WINCH OUT	WORK LIGHT

**Switch Label Applique Sheets #1 - #5 are included under part number 4110384C1.**

**5.7. Switch Label Applique Sheet #2 (Fire):**

AUX WARN	CAMERA LIGHT	CLEAR DISABLE	CLEAR LIGHTS	DO NOT MOVE	DOOR AJAR
DOOR OPEN	DUMP CLOSED	DUMP OPEN	HAZARD IND	HIGH IDLE	LADDER
LEFT SCENE	LF DUMP CLOSE	LF DUMP OPEN	LIGHT BAR	LIGHT TOWER	LOWER WARN
OK TO HI IDLE	OK TO PUMP	OPTI COM	PRIMARY WARN	PUMP & ROLL	PUMP MODE
REAR EMERG	REAR SCENE	RIGHT SCENE	ROAD MODE	ROOF EMERG	RR DUMP CLOSE
RR DUMP OPEN	RT DUMP CLOSE	RT DUMP OPEN	SECND WARN	SIREN	UPPER WARN

**Switch Label Applique Sheets #1 - #5 are included under part number 4110384C1.**

**5.8. Switch Label Applique Sheet #3 (Limo/Bus/Propane):**

A/C	AUX HEAT	BACK ALARM	BAR LIGHTS	BATH PUMP	BELLY VALVE
BRK INT. OVERRIDE	CABIN LIGHTS	CEILING LIGHT	CLOSE GATE	DOME LIGHT	DRIVE LIGHTS
DUMP VALVE	EMERG STOP	FAN	FAN 1	FAN 2	FLOOR HEATER
FLOOR LIGHTS	FRONT A/C	HEAT 1	HEAT 2	HEATED MIRROR	HOSE REEL
INTERNAL VALVE	LASER LIGHTS	LIFT ENABLE	MAP LIGHT	NEON LIGHTS	NOZZLE N/STOW
OPEN GATE	OVERIDE	PA POWER	REAR A/C	REAR DELIVRY	REEL GATE
ROOF A/C	ROOF LIGHT	SELF TEST	SIDE DELIVRY	SIDE EVAC	SIDE GATE
SPRAY FILL	STEP HEATER	TV	VAPOR VALVE	WHEEL CHAIR	WHEEL CHOCK

**Switch Label Applique Sheets #1 - #5 are included under part number 4110384C1.**

**5.9. Switch Label Applique Sheet #4 (Airport Refueler/Concrete Mixer):**

B LOAD GATE	BODY RAISE	BOTTOM LOAD	BRAKE INTERLCK	CHUTES	CHUTES DOWN
CHUTES LOCK	CHUTES UNLOCK	CHUTES UP	DEAD MN SWITCH	DEFUEL VALVE	DRUM CHRG
DRUM DISCHRG	DRUM START	DRUM STOP	EXT SPEAKER	EXTEND	FRT OW NOZZLE
HIGH WATER	HOPPER	HOPPER DOWN	HOPPER LIGHT	HOPPER UP	HYD
LEFT CHUTE	MACHINE	MASTER POWER	MID START	MID STOP	PUSHER DOWN
PUSHER UP	REAR CHUTE	REFER FUEL	REMOTE OVERRIDE	RETRACT	RIGHT CHUTE
SUMMER	THROTL	THROTL ENABLE	TOOL CIRCUIT	TRAILER ACTIVE	TRUCK
U WING NOZZLE	VACUUM	WATER	WATER PUMP	WING LIGHT	WINTER

**Switch Label Applique Sheets #1 - #5 are included under part number 4110384C1.**

**5.10. Switch Label Appliance Sheet #5 (Plow/Dump):**

ALT FLASH	AUGER FORWRD	AUGER REVERSE	AUTO CHAINS	AUX 1	AUX 2
AUX 3	BODY LOWER	BODY OVERHT	BODY UP	CLOSE DOOR	CONVEYR
FAN HIGH	FAN LOW	GATE DOWN	GATE OPEN	GATE UP	HIGH RAIL
HYD FILTER	HYD OIL HI TEMP	HYD OIL LOW	HYD OVERRIDE	LIQUID LEVEL	LOCK DOOR
LOW SALT	LOWER BED	LOWER BOX	OPEN DOOR	PACK	PLOW BALANCE
PLOW DOWN	PLOW LEFT	PLOW LIGHT	PLOW RIGHT	PLOW UP	PRE-WET
PUMP ENGAGED	RAISE BED	RAISE BOX	SANDER	SHAKER	SPREDR
SPREDR LIGHT	TARP UNWIND	TARP WIND	T-GATE DOWN	T-GATE UP	UNLOCK DOOR

**Switch Label Appliance Sheets #1 - #5 are included under part number 4110384C1.**

### 5.11. Switch Label Applique Sheet #6 (Tanker)

ATF PUMP	AUTO	AXLE 1 DOWN	AXLE 2 DOWN	CLEAR WARN	COMPRS PTO
DRAIN VALVE	FILL VALVE	HYD PUMP	IN REVERSE	INJECT SYSTEM	LEFT PTO
LEFT WING	LIFT	LOW FLO HOSE	MTR OIL PUMP	NEUTRAL	PRINTER POWER
PTO 1	PTO 2	PTO CURB	PTO DIESEL	PTO GAS	PTO OVERRIDE
PTO STREET	PUMP HIGH	PUMP LOW	PUMP PANEL	PURGE	REAR WORK
REGEN ON	RIGHT PTO	RIGHT WING	ROOF HATCH	SENSOR POWER	SUSP KNEEL
TAG DOWN	TANK EMPTY	TANK 1 CLOSED	TANK 1 OPEN	TANK 2 CLOSED	TANK 2 OPEN
TANK 3 CLOSED	TANK 3 OPEN	TANK 4 CLOSED	TANK 4 OPEN	TANK VENTS	VAPOR PUMP

Switch Label Applique Sheet #6 Part Number 2518768C1

**5.12. Switch Label Applique Sheet #7 (Ambulance/Fire):**

110 V INVT	12 VOLT OUTLET	AIR HORN	ALLEY	ALLEY LIGHTS	CITY HORN
CODE AMBER	CODE BLUE	CODE GREEN	CODE RED	DRIVER ALLEY	ELECT HORN
EMERG MASTER	EXHST FAN	FRONT CENTER	FRONT FLASH	FRONT LIGHT	FRONT WARN
INTSEC LIGHTS	LADDER N/STOW	LAMP OUT	LEFT ALLEY	LEFT CENTER	LEFT FRONT
LEFT REAR	LEFT WARN	LOAD MNGR	MASTER THROTL	METEOR LIGHT	MNGR CANCEL
OXYGEN	OXYGEN LIGHT	PASS ALLEY	PERM LIGHT	PTO GEN	REAR ALLEY
REAR CENTER	REAR WARN	RIGHT ALLEY	RIGHT CENTER	RIGHT FRONT	RIGHT REAR
RIGHT WARN	SIDE WARN	SIREN BRAKE	SIREN HORN	STEP LIGHT	STEP LT CANCEL


**Switch Label Applique Sheet #7 Part Number 2518769C1**

**5.13. Switch Label Applique Sheet #8 (Adv Fire/Ambulance):**

A/C HEAT	CENTER DOME	COOL	DOCK LIGHTS	DRIVER DOME	ELECT SUCTION
FRONT ALARM	FRT RAIL LIGHTS	GEN	HEAT	HIGH THROTL	HOSE LIGHTS
LADDER DOWN	LADDER LIGHTS	LADDER PTO	LADDER UP	LEFT COT	LEFT DOME
LEFT EVAC	LEFT WORKLTS	LOW THROTL	LOWER EMERG	LOWER IDLE	LRC III POWER
METER POWER	OK TO THROTL	OUTRIG UP	POLE LIGHT	POWER	PUMP
PUMP 1	PUMP 2	RADIO REMOTE	RAISE IDLE	REAR RAIL LIGHTS	REAR CAMERA
RF POWER	RIGHT COT	RIGHT DOME	RIGHT WORKLTS	START GEN	TOWER DOWN
TOWER UP	WAIL	WATER CANNON	WHEEL LIGHTS	XFER CASE	YELP

**Switch Label Applique Sheet #8 Part Number 2518770C1**

**5.14. Switch Label Applique Sheet #9 (On/Off/Blank):**



**Switch Label Applique Sheet #9 Part Number 2518771C1**

**5.15. Switch Label Applique Sheet #10 (Miscellaneous):**

ARROW SPLIT	BATH ASSIST	BATH LIGHT	BLOWER	BOOM LEFT	BOOM RIGHT
CHARGER POWER	CRANE DOWN	CRANE EXTEND	CRANE LEFT	CRANE RETRACT	CRANE UP
CAB ROTO	DIESEL GEN	DIESEL HEATER	DIESEL PUMP	ELECT MAGNET	FLORES LIGHT
FOG LIGHTS	FRONT SCENE	FRONT SWEEP	HYD SHUTDN	LAMP TEST	LEFT FLOOD
LEFT READ	LEFT SWEEP	LIFT GATE	LOW PRES	LOW VOLTS	NOT LEVEL
OIL LEVEL	OVER LOAD	OVER TEMP	PACKER LEFT	PACKER ON	PACKER RIGHT
REAR SWEEP	REFER TEMP	RIGHT FLOOD	RIGHT READ	RIGHT SWEEP	SHRED POWER
SHUT DOWN	START	STOP	SUSP RAISE	VAC OFF	VAC ON

**Switch Label Applique Sheet #10 Part Number 2518772C1**

## 6. Customized Steering Wheel Switches

**0008XPG:** STEERING WHEEL CONTROLS (2) Customizable Switch Pods

**0008XPH:** STEERING WHEEL CONTROLS Customizable Switch Pod

Steering wheel switches include a right-side pod and a left-side pod. Steering wheel switches have several configurations and part numbers.

Body Builder Variant 1 - Blank	4307659C91	
Body Builder Variant 2 - Cruise, Marker Interrupt, Blank	4324016C91	
Body Builder Variant 3 - Cruise, Blank	4330394C91	

### Steering Wheel Switch Pod Configurations

Customer applications can be customized by using the part number configurations from the table above.

Note: Clock spring part numbers and steering column harnesses may need to be changed, depending on the desired changes and what was built on the truck.

## **Steering Wheel Switch Label Configurations**

Note: The switches can be labeled using the stickers provided with part number 4333919C1.

Note: Refer to the appropriate integration guide for the most up to date information.

Steering wheel switches have labels to use on each steering wheel switch pod. Depending on the customer application, different labels will be used. Refer to the appropriate integration guide for detailed steering wheel switch label configurations.

**Stickers Provided with 4333919C1**



**Sample of Sheet Provided with 4333919C1**

## Body Controller Software Feature Codes:

Custom switch configuration requires combinations of various feature codes. Feature codes 597080 is the left-side pod and 597098 is the right-side pod. They are required if the corresponding pod is required in the steering wheel. These feature codes set up the analog inputs to the BCM from the switches.

Feature	Description	Installed	Ad...	Remove...
0597080	BCM PROG, STEER WHEEL SWITCHES, Left Hand Pod			
0597098	BCM PROG, STEER WHEEL SWITCHES, Right Hand Pod			
0597649	BCM PROG, STEER WHEEL SWITCHES, Left Hand Pod use for c...			
0597650	BCM PROG, STEER WHEEL SWITCHES, Right Hand Pod use for ...			
0597619	BCM PROG, CRUISE CONT STEER WH Adaptive Cruise Follow C...			
0597071	BCM PROG, MARKER INTERRUPT SW Located in Steering Wheel			
0597078	BCM PROG, HEADLIGHT INTERRUPT Located in Steering Wheel			
0597081	BCM PROG, CRUISE CONT STEER WHEEL			
0597177	BCM PROG, CRUISE CONT STEER WH Cluster Version #2			

**Features as Shown in DLB**

Note: All features associated with the (R/L) switch pod intended to be used for custom application must be removed/ not included in the configuration these include, but may not be limited to:

- Feature code 597071– Marker Interrupt Switch
- Feature code 597078 – Headlight Interrupt Switch
- Feature code 597081 – Cruise Cont. Steer Wheel
- Feature code 597145 – Radio Controls
- Feature code 597177 – Cruise Control Switch
- Feature code 597619 – Adaptive cruise selectable following distance
- Feature code 597620 – Adaptive cruise selectable following distance for fusion 3.0

Note: Cruise control functionality can be relocated from the steering wheel pods to the Mux Switch pack in the IP using feature code **597528**

Note: Both the feature for the installed side pod and the use of that pod for custom application must be configured:

Electrical feature code required	Left pod	Right pod
Add Pod to configuration	597080	597098
Enable Pod for custom application	597649	597650

## Advanced Logic Programming

Note: Advanced logic programming, written with DLB, is required to enable the steering wheel switch customer Applications. The physical steering wheel pod switches are all discrete, normally open and momentary contact. The input signals used in DLB that read the switches are also normally open contacts like most input contacts in DLB are. If latching operation of the output is desired a software latch must be used, one efficient method is to use an intermediate variable with a toggle modifier this also requires an edge modifier on the input to ensure proper controlled operation.

The screenshot displays the International Diamond Logic Builder interface. The main window shows a ladder logic diagram with the following rungs:

- Rung 1: DLB\_Right\_Steering\_Wheel\_Switch\_1 (NO contact) connected to rtStSw1Var (coil).
- Rung 2: DLB\_Right\_Steering\_Wheel\_Switch\_1 (NO contact) connected to LatchedOutput1 (coil).
- Rung 3: rtStSw1Var (NO contact) connected to RPM1\_Output1 (coil).
- Rung 4: DLB\_Right\_Steering\_Wheel\_Switch\_3 (NO contact) connected to MomentaryOutput\_12vOut (coil).
- Rung 5: DLB\_Right\_Steering\_Wheel\_Switch\_3 (NO contact) connected to RPM1\_Output2 (coil).
- Rung 6: on (NO contact) connected to an unlabeled coil.

The right-hand pane shows a table of variables:

My Variables	Advanced	Chassis	Cluster	Datalink	Engine	Engine Control	Indicators
DLB_Right_Steering_Wheel_Switch_1	..	DLB_Right_Steering_Wheel_Switch_1					On/Off
DLB_Right_Steering_Wheel_Switch_3	..	DLB_Right_Steering_Wheel_Switch_3					On/Off
LatchedOutput1	..	RPM1_Output1					On/Off
MomentaryOutput_12vOut	..	RPM1_Output2					On/Off
latchedOutput1_12VOut	..						On/Off
rtStSw1Var	..						On/Off

The status bar at the bottom indicates "Waiting for connection..."

### Advanced Logic Sample

## 7. Lighting Control Module:

### 7.1. Lighting Control Module Housing:



*LCM (Pictured example Configured with Auto Light Ctrl & Fog Lights)*

### 7.2. Lighting Control Module and Associated Parts:

PART NUMBER	DESCRIPTION
<b>LIGHTING CONTROL MODULES</b>	
4080940C3	HOUSING SWITCH LIGHT CONTROL MODULE W/AUTO, FOG LIGHT
4086867C3	HOUSING SWITCH LIGHT CONTROL MODULE W/FOG

#### **Lighting Control Module Variants**

## 8. Remote Power Modules:


Note: Remote power modules are not currently available as an orderable feature on electric vehicles. Body builders can add them by obtaining and installing the required parts, adding the required programming, and adding the required wiring.

Remote power modules provide a method of distributing and controlling power to various device loads on the vehicle, outside the cab, without running high current wires from in-cab switches to the loads or splicing into existing wiring.

The RPM is connected to the BCM via the Body Builder J1939 datalink (the BCM is capable of controlling up to seven RPMs on the vehicle). The only factory-installed wires connected to the RPM are battery power for driving the loads and the datalink cable. Connectors for Body Builder-installed inputs and outputs are also provided. Power is fed to the RPM through a fusible link to the battery source. Each RPM has six independently controllable, 20 Ampere (AMP) outputs (80 maximum per RPM) with virtual (software programmable) fusing similar to the BCM. If higher current capacity is needed, two outputs can be paralleled, or the RPM can control a high current relay while still maintaining logic and diagnostic capability without having to wire to the inside of the cab.

Because the RPM is connected to the BCM via the datalink, it also serves as an “integration gateway” to the BCM and the vehicle electrical system. Six inputs on each RPM allow information from body accessories to be communicated to the BCM and processed for interlocks, operator information/warning, etc. These inputs also allow the Body Builder to add body-mounted switches to turn on or off the same electrical devices controlled by in-cab switches.

### 8.1. Remote Power Module Composite View




**Remote Power Modul End and Top Views**

PART NUMBER	DESCRIPTION
2588909C95	REMOTE POWER MODULE

### Remote Power Module


## 8.2. Remote Power Module CAN Pass-through Connector



PART NUMBER	DESCRIPTION
2005240C1	6-WAY CONNECTOR
200242C1	6-WAY CONNECTOR LOCK
453133C1	CONNECTOR PLUG
2034787C1	WIRE TERMINAL 14-GAUGE
1680205C1	WIRE TERMINAL 16-GAUGE
1651988C1	WIRE TERMINAL 18-GAUGE
1651969C1	WIRE TERMINAL 20-GAUGE

### Remote Power Module 6-Way J1939 Datalink Connector

### 8.3. Body Equipment Power Output Connector




PART NUMBER	DESCRIPTION
3548934C1	8-WAY CONNECTOR
3548943C1	8-WAY CONNECTOR LOCK
2025431C1	CONNECTOR PLUG
3434163C1	WIRE TERMINAL 12-GAUGE
3935931C1	WIRE TERMINAL 14-GAUGE
3535930C1	WIRE TERMINAL 16-GAUGE
3548945C1	WIRE TERMINAL SEAL 12-GAUGE
3535937C1	WIRE TERMINAL SEAL 14-GAUGE
3535936C1	WIRE TERMINAL SEAL 16-GAUGE

#### Remote Power Module 8-Way Output Connector

## 8.4. Body Equipment Signal Input Connector


### 23-Way Remote Power Module Input J3 Connector



PART NUMBER	DESCRIPTION
2588914C1	23-WAY CONNECTOR
1688285C1	CONNECTOR PLUG
1698937C1	WIRE TERMINAL 16/18/20-GAUGE

**Remote Power Module 23-Way Input Connector**


### 8.5. Remote Power Module Address Jumper Locations



PART NUMBER	DESCRIPTION
2588908C92	ADDRESS JUMPER KIT

**Remote Power Module Address Jumper Source Addressing Schemes**

### 8.6. Remote Power Module Power Connections



**Remote Power Module High Current Battery Connectors**

## 9. Instrument Panel

### Instrument Panel



#### Instrument Panel Overview:

- The base instrument panel configuration can accommodate one 6-pack module location.
- Currently, there are no options available to add additional switched output functions in the switch pack.
- Currently, there are no options to add additional switch packs.
- The drive mode selector determines the desired direction of travel.
- The In-cab fuse and relay panel is under a cover, on the dash, in front of the passenger seat.

## 10. Air Conditioning

**16BAM:** Air Conditioner with Integral Heater and Defroster

**Extended Description:** This feature provides HVAC controls for the cab environment. The system uses a high voltage electric compressor. There are no options for this system to be modified by Body Builders and there are no accommodations to add additional compressors.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 11. 12 Volt System

**Caution** – To prevent damage to components, refer to the information, on removing the “Red Gel Coat,” provided in the Appendix.

### 11.1. 12-VOLT BATTERY CHARGING

The 12-Volt batteries are charged by 2 DC to DC converters that convert high voltage to approximately 14 volts.

Each Converter has a power rating of 4000 Watts and a maximum current capacity of 278 Amps.

The converters are mounted underneath the 12 Volt battery box or in the compartment under the cab below the driver.

Newer models may have the battery located under the hood.

The converters and the batteries are all connected in parallel.


The converter positive outputs tie together and terminate at the battery disconnect switch.

The negative outputs tie together and terminate at a chassis ground.

The battery positive circuits tie to the same spot as the converter circuit, at the disconnect switch.

The circuits on the other side of the disconnect switch go to the 12-volt PDM, in the under-hood compartment.

**Caution** – To prevent damage to components, refer to the information, on removing the “Red Gel Coat,” provided in the Appendix.



Component Locations

1.	Battery Box	2.	DC to DC Converter #2
3.	Skid Plate	4.	DC to DC Converter #1
5.	Battery Disconnect Switch Location		

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:


Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 11.2. 08RMH: BATTERY DISCONNECT SWITCH Cole-Hersee 75920-06} 300 Amp, Disconnects Charging Circuits, Locks with Padlock, Battery Box Mounted.

**Extended Description:** The battery disconnect switch is used to shut down the entire 12 Volt battery-fed electrical system. This switch will shut off the system so that the electrical components on the vehicle, if left on, do not drain the batteries. This switch also disables the control to the High-Voltage system.

08RMH provides a lever operated battery disconnect switch, which can be “locked out”.

### System Block Diagram:



### How to Test This Feature:

1. Close switch.
2. Verify that the vehicle is providing 12-14 Volts to the power distribution box.
3. Open disconnect switch.
4. Verify vehicle systems do not have any 12-volt electrical power.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**POWER DISTRIBUTION MODULE AND FUSES**

Additional body builder loads can be added to the power distribution modules and/or the fuse and relay panel.

**Caution** – To prevent damage to components, refer to the information, on removing the “Red Gel Coat,” provided in the Appendix.

Information on the power distribution modules and fuse locations can be found in the Operator’s Manual, Circuit Diagrams and the Service Manual.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**12. Body Builder Wiring, for Stop/Turn/Tail Lights/ Through Power:**


**12.1. 08HAA:** BODY BUILDER WIRING To EOF, With Stop, Tail, Turn, and Marker Lights Circuits, Ignition (IGN)-Controlled Auxiliary Feed and Ground (GND), Less Trailer Socket.

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** This feature is for vehicles that have heavy-duty lighting requirements. This feature has a 30-AMP IGN Feed. Right and left turn signals can support up to seven turn lamps per side. Code 08HAA is designed for separate stop and turn lamps only. The 7-wire breakout is located at the EOF and there is no connector. The wires are blunt cut with heat shrink covering.

## System Block Diagram:



## Body Controller Software Feature Codes:

- 597054 – BCM PROG, TRAILER LIGHTING

## Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Trailer_Left_Turn_Lamp_OC_Current	3175	Trailer Left Lamp Open Circuit Detection Level value range	0	A	0	20	0.1
Trailer_Left_Turn_Lamp_Low_Current	3177	Trailer Left Lamp Low Current Detection Level value range	0	A	0	20	0.1
Trailer_Left_Turn_Lamp_High_Current	3178	Trailer Left Lamp High Current Detection Level value range	15	A	0	20	0.1
Trailer_Right_Turn_Lamp_High_Current	3179	Trailer Right Lamp High Current Detection Level value range	15	A	0	20	0.1
Trailer_Right_Turn_Lamp_Low_Current	3180	Trailer Left Lamp Low Current Detection Level value range	0	A	0	20	0.1
Trailer_Right_Turn_Lamp_OC_Current	3181	Trailer Left Lamp Open Circuit Detection Level value range	0	A	0	20	0.1
Trailer_Marker_Lamp_High_Current	3182	Trailer Marker Lamp High Current Detection Level value range	20	A	0	20	0.1
Trailer_Marker_Lamp_Low_Current	3183	Trailer Marker Lamp Low Current Detection Level value range	0	A	0	20	0.1
Trailer_Marker_Lamp_OC_Current	3184	Trailer Marker Lamp Open Circuit Detection Level value range	0	A	0	20	0.1
Trailer_Tail_Lamp_High_Current	3185	Trailer Tail Lamp High Current Detection Level value range	20	A	0	20	0.1
Trailer_Tail_Lamp_Low_Current	3186	Trailer Tail Lamp Low Current Detection Level value range	0	A	0	20	0.1
Trailer_Tail_Lamp_OC_Current	3187	Trailer Tail Lamp Open Circuit Detection Level value range	0	A	0	20	0.1

## Parameter Definitions:

- **Trailer\_Left\_Turn\_Lamp\_OC\_Current** – This parameter sets the minimum fuse level for the open circuit of the Trailer Left Turn Lamp. If the current draw is below this value, a fault will be set.
- **Trailer\_Left\_Turn\_Lamp\_Low\_Current** – This parameter sets the minimum fuse level for normal operation of the Trailer Left Turn Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Left\_Turn\_Lamp\_High\_Current** – This parameter sets the maximum fuse level for normal operation of the Trailer Left Turn Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Right\_Turn\_Lamp\_High\_Current** – This parameter sets the maximum fuse level for normal operation of the Trailer Right Turn Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Right\_Turn\_Lamp\_Low\_Current** – This parameter sets the minimum fuse level for normal operation of the Trailer Right Turn Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Right\_Turn\_Lamp\_OC\_Current** – This parameter sets the minimum fuse level for the open circuit of the Trailer Right Turn Lamp. If the current draw is below this value, a fault will be set.
- **Trailer\_Marker\_Lamp\_High\_Current** – This parameter sets the maximum fuse level for normal operation of the Trailer Marker Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Marker\_Lamp\_Low\_Current** – This parameter sets the minimum fuse level for normal operation of the Trailer Marker Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Marker\_Lamp\_OC\_Current** – This parameter sets the minimum fuse level for the open circuit of the Trailer Marker Lamp. If the current draw is below this value, a fault will be set.
- **Trailer\_Tail\_Lamp\_High\_Current** – This parameter sets the maximum fuse level for normal operation of the Trailer Tail Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Tail\_Lamp\_Low\_Current** – This parameter sets the minimum fuse level for normal operation of the Trailer Tail Lamp. If the current draw exceeds this value, the circuit will open.
- **Trailer\_Tail\_Lamp\_OC\_Current** – This parameter sets the minimum fuse level for the open circuit of the Trailer Tail Lamp. If the current draw is below this value, a fault will be set.



**Arrow Indicates Location of Lighting Circuits**

**How to Add This Feature:**

**NOTE** - This feature is not easy to install, and every effort should be made to order the vehicle with the desired code. Refer to the 7-way blunt cut wires at EOF for information covering circuit connections and use of the circuit diagram manual to aid in assembly.

**How to Test This Feature:**

1. Turn on vehicle headlights.
2. Verify that the taillight circuit has battery voltage levels present.
3. Verify that the marker light circuit has battery voltage levels present.
4. Turn off vehicle headlights.
5. Turn on left turn signal in vehicle.
6. Verify that left turn circuit is cycling between battery voltage and GND.
7. Turn off vehicle left turn signal.
8. Turn on right turn signal in vehicle.
9. Verify that right turn circuit is cycling between battery voltage and GND.
10. Turn off vehicle left turn signal.
11. Put the vehicle in reverse.

12. Turn the key to the accessory or IGN position.
13. Verify that the IGN circuit has battery voltage levels present.
14. Press the vehicle brake pedal.
15. Verify that the stop circuit has battery voltage levels present.
16. Release brake pedal.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International's Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 13. CB and 2-Way Radio Accommodation Packages


**13.1. 08RNC:** CB RADIO Accommodation Package, Header Mounted, Feeds from Accessory Side of Ignition Switch, Includes Power Source, Two Antennas and Antenna Bases with Wiring on Both Side Mirror

**Feature Applicability to Vehicle Platforms:**

- (eMV)

**Extended Description:** When installing a CB radio, this feature provides the power circuits required for hook-up. This accommodation package includes a two-way connector with a 10-Amp accessory power feed and cab ground, dual CB antenna cables routed from the mirrors to the cab overhead console panel opening and two CB antenna mounts located at the top of each mirror. A strap is also provided in the header to mount the customer-supplied CB radio. The antennas are not provided with this code. If the two antennas are desired, 08RBK must be ordered.

**System Block Diagram:**



**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
1661196C1	2-WAY CONNECTOR, BODY
1661209C1	WIRE TERMINAL 16-GAUGE

**Parts Associated with CB Radio Mating Connector**

**How to Test This Feature:**

To test these circuits, verify that battery voltage is present in the correct key-state for each respective feature.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 14. Fog Light Package


### 14.1. 08XJH: FOG LIGHTS (2) Clear Lens, LED, Rectangular, with White Light Source

#### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** Feature code 08XJH comes with the fog light system (wiring and fog light lamps) completely installed. 08XJH operates as follows: to turn on the fog lamps; the headlamps must be on and in the low beam position. The lamps will go off if the headlamps are switched to high beam. 08XJH is available on eMV models.

#### System Block Diagram:



#### Body Controller Software Feature Codes: (Feature code and description goes below)

- 597011 - BCM PROG, FOG LIGHT (LCM)

#### Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Left_Fog_Light_Hi_Current	2309	Left Fog Light High Current Detection Level (Amps)	10	A	0	10	0.1
Left_Fog_Light_Lo_Current	2310	Left Fog Light Low Current Detection Level (Amps)	0.5	A	0	10	0.1
Left_Fog_Light_OC_Current	2311	Left Fog Light Open Circuit Detection Level (Amps)	0.5	A	0	10	0.1
Right_Fog_Light_Hi_Current	2312	Right Fog Light High Current Detection Level (Amps)	10	A	0	10	0.1
Right_Fog_Light_Lo_Current	2313	Right Fog Light Low Current Detection Level (Amps)	0.5	A	0	10	0.1
Right_Fog_Light_OC_Current	2314	Right Fog Light Open Circuit Detection Level (Amps)	0.5	A	0	10	0.1

**Parameter Definitions:**

- **Left\_Fog\_Light\_Hi\_Current** - If the current in the left fog light circuit exceeds the level set by this parameter, the Body Controller (BCM) will shut off the circuit and register a fault code.
- **Left\_Fog\_Light\_Lo\_Current** - If the current in the left fog light circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.
- **Left\_Fog\_Light\_OC\_Current** - This parameter detects open circuit in the left fog light, the Body Controller (BCM) will register a fault code.
- **Right\_Fog\_Light\_Hi\_Current** - If the current in the right fog light circuit exceeds the level set by this parameter, the Body Controller (BCM) will shut off the circuit and register a fault code.
- **Right\_Fog\_Light\_Lo\_Current** - If the current in the right fog light circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.
- **Right\_Fog\_Light\_OC\_Current** - This parameter detects open circuit in the right fog light, the Body Controller (BCM) will register a fault code.

**Note/s About Possible Software Feature Conflicts:** NONE

**Parts Associated with This Feature:**

PART NUMBERS	DESCRIPTION
<b>FOG LIGHT CONNECTOR (FEMALE CONNECTOR BODY)</b>	
587567C91	2-WAY CONNECTOR BODY
1673748C1	WIRE TERMINAL 12-GAUGE
587577C1	WIRE TERMINAL 14/16-GAUGE
589391C1	WIRE TERMINAL SEAL 12-GAUGE
1667735C1	WIRE TERMINAL SEAL 14/16-GAUGE
<b>FOG LIGHT CONNECTOR (MALE CONNECTOR BODY)</b>	
587568C91	2-WAY CONNECTOR BODY (DELPHI WEATHERPACK SEALED 2.6MM FEM 2W 20 AMPS)
1673747C1	WIRE TERMINAL 16-GAUGE (DELPHI WEATHERPACK 2.6MM MALE 12 AWG)
587575C1	WIRE TERMINAL 16-GAUGE (DELPHI WEATHERPACK 2.6MM MALE 16-14 AWG)
589391C1	WIRE TERMINAL 12-GUAGE (DELPHI BLUE 1W CAVITY SEAL PN:15324996)
1667735C1	WIRE TERMINAL 16-GUAGE (DELPHI BLUE 1W CAVITY SEAL PN:15324996)

**Parts Associated with Fog Light Feature**

**How to Test This Feature:**

1. Activate fog light switch with the IGN key on and the headlamp switch on the low-beam mode.
2. Verify that pin F (labeled Left\_Front\_Fog\_Light) and pin K (labeled Right\_Front\_Fog\_Light) in DLB located in connector (#1603 J1) are providing battery voltage.
3. Verify that the fog lights are functioning correctly.
4. Turn the fog light switch OFF.
5. Verify that the fog light output goes OFF.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 15. Gauges and Fault Code Display

### 15.1. 16HKA IP CLUSTER DISPLAY Omit Display of Diagnostic Trouble Codes in Instrument Cluster and Disable Blink Codes, Requires Service Tool to Retrieve and View Fault Code

**Description:** The instrument cluster on the electric vehicle does not have the ability to display diagnostic trouble codes. Codes can be retrieved by connecting with a service tool.

## 16. In Cab Battery Feed and USB Power Source



### 16.1. 08XPK: POWER SOURCE, ADDITIONAL Auxiliary Power Outlet (APO) with USB-A Port and USB-C Port, Located in the Instrument Panel.

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** This feature provides a power source for customers who wish to use CB radios, handheld spotlights, trouble lights or other accessories that plug into the cigar type receptacle for 12-volt power. It also provides USB-A and USB-C ports for powering and charging compatible devices.

### System Block Diagram:



### How to Test This Feature:

To test these circuits, refer to the applicable circuit diagram for the feature and verify that battery voltage and USB voltage is present in the correct key-state.

### References:

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics


## 16.2. 08XPL: POWER SOURCE, ADDITIONAL Auxiliary Power Outlet (APO) with Two USB-A Ports and Two USB-C Ports, Located in the Instrument Panel.

### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** This feature provides additional USB-A and USB-C ports for powering and charging compatible devices.

**System Block Diagram:**



**How to Test This Feature:**

To test these circuits, refer to the applicable circuit diagram for the feature and verify that USB voltage is present in the correct key-state.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics


**16.3. 08XPN: USB PORT** One USB-A Port and one USB-C Port, Located in the Instrument Panel.

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** This feature provides USB-A and USB-C ports for powering and charging compatible devices.

**System Block Diagram:**



**How to Test This Feature:**

To test these circuits, refer to the applicable circuit diagram for the feature and verify that USB voltage is present in the correct key-state.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics



**16.4. 08XPP: USB PORT Two USB-A Ports and Two USB-C Ports, Located in the Instrument Panel.**

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** This feature provides USB-A and USB-C ports for powering and charging compatible devices.

**System Block Diagram:**



**How to Test This Feature:**

To test these circuits, refer to the applicable circuit diagram for the feature and verify that USB voltage is present in the correct key-state.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

## 17. Liftgate Accommodation Package

**17.1. 08VBA: POWER SOURCE, SPECIAL for Customer Installed Lift Gate; 200 Amp Max,** Includes 00ga. Power Cable to End of Frame, Optional Power (PDM) for Power Source, Latched Switch on Instrument Panel, with a Time Out Feature, Battery Discharge Protection, Controlling a Mag Switch Which Provides Power.

### **Feature Applicability to Vehicle Platforms:**

- eMV


**Extended Description:** 08VBA includes a 15-foot power cable coiled at the end of the frame to provide power for operating a lift gate. This feature is battery fed through a chassis Power Distribution Module (PDM) The feature includes a 200-Amp circuit breaker located in the chassis PDM.

When the lift gate is requested via the dash switch or the Remote Keyless Entry, it sends a signal to the BCM over the 125K J1939 communication network. The BCM processes the lift gate enable request when interlocks such as battery voltage, vehicle speed, and lift gate enable timer are met. The BCM activates lift gate contactor solenoid, which then sends voltage to the lift gate. This feature provides battery protection with visual and audible indication to the operator that the BCM will deactivate the lift gate output to prevent excessive discharge of the batteries.

Lift gate contactor internal solenoid is energized by the Body Control Module (BCM) with input from the lift gate switch. After contactor solenoid is energized, an optional Chassis PDM supplies voltage to lift gate contactor which then outputs voltage for raising and lowering lift gate. If vehicle is not equipped with optional Chassis PDM, vehicle batteries supply voltage to lift gate contactor.

If the lift gate enable switch is on and the 12-volt battery voltage drops below the threshold limit for a programmable amount of time, the audible alarm will come on and the switch indicator will flash for a programmable amount of time.

## System Block Diagram:



0000431229

## Body Controller Software Feature Codes: (Feature code and description goes below)

- 597309 - BCM PROG, LIFT GATE WIRING PAK Rocker Position with a Time Out Feature, Battery Discharge Protection

## Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Lift_Gate_Alarm_Time	2249	Lift Gate Alarm time value.	60	s	1	120	1
Lift_Gate_Enable_Timeout	2235	This signal is a parameter that can be adjusted to vary the amount of time, in 10-minute increments, that the lift gate will remain enabled. If this value is set to 6, the lift gate will remain enabled for 60 minutes from the time that it is enabled.	60	min	10	240	10
Lift_Gate_Disable_Threshold	2239	Battery voltage at which the feature is disabled.	12	V	11.5	13.8	0.1
Lift_Gate_Enable_High_Current	2234	Lift Gate Enable High Current Detection Level (Amps).	10	A	0	10	0.1
Lift_Gate_Enable_Lo_Current	2233	Lift Gate Enable Low Current Detection Level (Amps).	0	A	0	10	0.1
Lift_Gate_Enable_OC_Current	2232	Lift Gate Enable Open Circuit Detection Level (Amps).	0	A	0	10	0.1

## Parameter Definitions:

- **Lift\_Gate\_Alarm\_Time** - If battery voltage has dropped to or below programmable value (Lift\_Gate\_Voltage\_Threshold) for 'Lift\_Gate\_Alarm\_Time' the BCM will remove power from the Lift Gate Control output.
- **Lift\_Gate\_Enable\_Timeout** - programmable period of time for which BCM will provide power to the Lift Gate Control output, after Lift Gate Control is activated by Lift Gate Enable switch.
- **Lift\_Gate\_Diasable\_Threshold**- If the 12-volt battery falls below the level set by this parameter, the Body Controller (BCM) will disable the lift gate.
- **Lift\_Gate\_Enable\_High\_Current** - If the current in the lift gate contactor circuit exceeds the level set by this parameter, the Body Controller (BCM) will shut off the circuit and register a fault code.
- **Lift\_Gate\_Enable\_Lo\_Current** - If the current in the circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.
- **Lift\_Gate\_Enable\_OC\_Current**- If the current in the circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.



**Arrow Indicates Location of Lift Gate Power Circuit**

**Parts Associated with This Feature:**

PART NUMBER	QTY	DESCRIPTION
3601546C1	2	NUT, STAINLESS NYLON M5 X 0.8
4041455C1	1	RELAY, GIGAVAC GX-11 CONTACTOR
R2H32R1024	1	CABLE, BATTERY, ASM, LIFT GATE, 12VDC CONTACTOR
3601544C1	2	BOLT, STAINLESS M5 X 0.8 X 35MM
4121522C1	1	COVER, TERMINAL
120380	1	LOCKWASHER, 1/4 REG STEEL/ZNC 1/4
4041531C94	1	ASSEMBLY, LIFT GATE POWER
25672R1	1	BOLT, 1/4 X 2-1/4 PHC TYPE 8
4041529C97	1	CABLE, ASSEMBLY, LIFT GATE POWER
4041530C92	1	CABLE, ASM, LIFTGATE SINGLE POLE COILED CABLE 15FT

**Lift Power Wiring Part Numbers**

**How to Test This Feature:**

1. The body builder or lift gate installer must bring the batteries up to a full charge before trying to test the system for functionality.
2. With the batteries at a full charge, voltage in the 12.6 to 12.9 range and the lift gate power controlled by the Battery Protection System, the system will operate as described in the Extended Description section.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 18. Power Window, Locks, Remote Keyless Entry

### 18.1. 16VDZ: KEYLESS ENTRY SYSTEM REMOTE with Panic and Auxiliary Work Light Function, Includes Two Key Fobs (Transmitters).


**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** Driver and passenger power windows and door locks are available. The driver switches are located on the driver door trim and can control all door windows and locks. The passenger switches are located on the passenger door trim and can control the passenger door window and all locks. Window express down is available for all window switches by momentarily depressing the window down switch. The driver can “lockout” all non-driver controllable window switches by momentarily depressing the lower left switch on the driver door control.

Feature 16VDZ requires that feature 16WJU in addition to one of the available Work Light accommodation features be installed on the vehicle in order to operate correctly. This feature assigns the Aux button on the keyless entry remote to control the work light output from the Body Control Module. When this feature is installed on the vehicle, the work light can be turned “ON” and “OFF” using the AUX button on the key fob.

**System Block Diagram:**



### Body Controller Software Feature Codes:

- 597103 - BCM PROG, KEYLESS ENTRY REMOTE
- 597107 - BCM PROG, REMOTE FOR WORKLIGHTS
  - Both features are required

### Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Panic_Enable	644	Enable/disable the Panic Mode for the Keyless Remote. A value of 1 enables and a value of 0 disables the feature.	ON	No_Units	N/A	N/A	N/A
Chirp_Enable	647	Enable/disable the remote lock "chirp" for Keyless Remote. A value of 1 enables and a value of 0 disables the feature.	ON	No_Units	N/A	N/A	N/A

**Parameter Definitions:**

- **Panic\_Enable** – When this parameter is set to ON. This enables the Panic Mode feature of the keyless remote. The panic function chirps the horn on/off in unison with the headlights and park lights for three minutes when the panic button on the key fob is pressed and the IGN switch is off. If the button is pressed prior to the time out period, the lights and horn will go off.
- **Chirp\_Enable** - When this parameter is set to ON. This enables the Chirp feature for the keyless remote. The chirp feature results in a “chirping” sound when the truck is locked and unlocked.

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
<b>DOOR POD RELATED PARTS</b>	
4057699C5	CONTROL, ELECTRONIC, POD PASS DOOR W/RKE
4060791C1	CONTROL, ELECTRONIC, TRANSMITTER, RKE DOOR POD
<b>WORK LIGHT (CHASSIS HARNESS CONNECTOR PARTS)</b>	
1661778C1	2-WAY CONNECTOR BODY
1661875C1	WIRE TERMINAL 16-GAUGE
1661874C1	CONNECTOR LOCK
1661872C1	WIRE TERMINAL SEAL 16-GAUGE
<b>WORK LIGHT (CHASSIS HARNESS MATING CONNECTOR PARTS)</b>	
3543888C1	2-WAY CONNECTOR BODY
1661874C1	CONNECTOR LOCK
1667742C1	WIRE TERMINAL 16-GUAGE
1661872C1	WIRE TERMINAL SEAL 16-GAUGE

**Parts Associated with Remote Keyless Entry System**

**Transmitter Learning Process:**

This is the “learning” process for teaching a remote entry transmitter (“Key fob”) to a passenger door pod mounted receiver.

The learning process begins by following the idiosyncratic steps delineate below:

- Step 1 – Simultaneously depress and hold both the lock and unlock buttons located in the passenger door pod.
- Step 2 – With both the lock and unlock buttons depressed, push down and release the passenger door pod’s window control switch actuator at least five times within a time interval of two seconds or less.
- Step 3 – Both lock and unlock buttons (located in the passenger door pod) can be released after completion of step 3.

- Step 4 – Depress any of the five buttons located on the RKE transmitter (Key fob).

**Exiting the Transmitter “Learning” process:**

- The door pod will exit the “learning” process once it enters the sleep state.
- Once the “learning” state has been successfully entered [Step 2] and there is no activity after 30-seconds the passenger door pod will automatically exit the RKE (Key fob) “learn” mode.

**NOTE** - While the passenger door pod is in the “learning” process as many as six RKE (Key fobs) may be “learned” to that single passenger door pod device. Simply depress any of the five buttons on each RKE (Key fob) [Step 4] to “learn” it to the passenger door pod. It is also important to note that while “learning” multiple RKE (Key fobs) to a single passenger door pod device that care is taken to sequentially “learn” the RKE (Key fobs) one at a time so not to confuse the process with multiple RKE (Key fob) transmitters broadcasting differing and simultaneous IP messages to the passenger door pod device.

**How to Test This Feature:**

1. Refer to the applicable feature code using Diamond Logic® Builder programming and diagnostic software to test programmed parameter signal list.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International’s Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 18.2. 16WJU: WINDOW, POWER (2-Door) and Power Locks, Left and Right Doors.


### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** Driver and passenger power windows and door locks are available. The driver switches are located on the driver door trim and can control all door windows and locks. The passenger switches are located on the passenger door trim and can control the passenger door window and all locks. Window express down is available for all window switches by momentarily depressing the window down switch. The driver can “lockout” all non-driver controllable window switches by momentarily depressing the lower left switch on the driver door control.

Feature 16WJU provides driver and passenger door pods for the control of power windows and locks for standard and extended cabs with two doors.

### System Block Diagram:



### Body Controller Software Feature Codes:

- 597061 - BCM PROG, POWER WINDOW/DR LOCK 2 DOORS

### Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
AutoLock_Speed	652	Autolock speed. The speed at which the vehicle doors will lock automatically (requires power locks); Setting this parameter to zero will disable Auto Door Locks.	15	MPH	0	155	1

### Parameter Definitions:

- **AutoLock\_Speed** – This parameter sets the vehicle speed at which the vehicle doors will lock automatically. A value of ZERO will disable the Auto Door Lock feature.

### How to Add This Feature:

Remote Keyless Entry (RKE) feature can be added if power windows/power locks (16WJU / 16WJV) are already installed on the vehicle by replacing the standard front passenger side door pod with an RKE compatible door pod.

- Software feature code 597061 must be removed, and software feature code 597103 be enabled on the vehicle using the Diamond Logic® Builder software (see local dealer).
- Remove the existing passenger side door pod and replace it with the RKE compatible pod, part number in table [below]. The desired quantity of remote key fobs, part number in table [below], must also be ordered.
- Set the applicable programmable parameters, chirp enable, panic enable - see above, using the Diamond Logic® Builder software (see local dealer). The auto lock with default vehicle speed option should already be set since power locks are installed.
- As noted above, additional wiring may be required if one or both of the Aux buttons on the key fob is to be utilized for the operation of a work light or other function/s.
- Program the RKE receiver to recognize the desired key fobs as described above.

### Parts Associated with This Feature:

PART NUMBER	DESCRIPTION
4057699C3	CONTROL, ELECTRONIC, POD PASS DOOR W/RKE
4060791C1	ELECTRONIC, TRANSMITTER, RKE DOOR POD

### Required Parts for Adding Remote Keyless Entry

### Transmitter Learning Process:

This is the “learning” process for teaching a remote entry transmitter (“Key fob”) to a passenger door pod mounted receiver.

The learning process begins by following the idiosyncratic steps delineate below:

- Step 1 – Simultaneously depress and hold both the lock and unlock buttons located in the passenger door pod.
- Step 2 – With both the lock and unlock buttons depressed, push down and release the passenger door pod’s window control switch actuator at least five times within a time interval of two seconds or less.

- Step 3 – Both lock and unlock buttons (located in the passenger door pod) can be released after completion of step 3.
- Step 4 – Depress any of the five buttons located on the RKE transmitter (Key fob).

**Exiting the Transmitter “Learning” process:**

- The door pod will exit the “learning” process once it enters the sleep state.
- Once the “learning” state has been successfully entered [Step 2] and there is no activity after 30-seconds the passenger door pod will automatically exit the RKE (Key fob) “learn” mode.

**NOTE** - While the passenger door pod is in the “learning” process as many as six RKE (Key fobs) may be “learned” to that single passenger door pod device. Simply depress any of the five buttons on each RKE (Key fob) [Step 4] to “learn” it to the passenger door pod. It is also important to note that while “learning” multiple RKE (Key fobs) to a single passenger door pod device that care is taken to sequentially “learn” the RKE (Key fobs) one at a time so not to confuse the process with multiple RKE (Key fob) transmitters broadcasting differing and simultaneous IP messages to the passenger door pod device.

**How to Test This Feature:**

1. Refer to the applicable feature code using Diamond Logic® Builder programming and diagnostic software to test programmed parameter signal list.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International’s Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**18.3. 16WKZ: KEYLESS ENTRY SYSTEM REMOTE with Panic and Auxiliary Buttons,**  
Includes One Key Fob (Transmitter).


**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** Driver and passenger power windows and door locks are available as well as power window control for rear cab doors on crew cabs. The driver switches are located on the driver door trim and can control all door windows and locks. The passenger switches are located on the passenger door trim and can control the passenger door window and all locks. Rear cab window controls are located on the left and right rear doors of the cab. Window express down is available for all window switches by momentarily depressing the window down switch. The driver can “lockout” all non-driver controllable window switches by momentarily depressing the lower left switch on the driver door control.

Feature 16WKZ provides a key fob for remote keyless entry into the cab of the vehicle. The key fob includes buttons to lock/unlock the cab doors, a Panic alarm button to sound the city horn and an Auxiliary button that can be utilized with advanced logic programming for customer desired functionality. This feature requires 16WJU or 16WJV is also installed on the vehicle.

## System Block Diagram:



## Body Controller Software Feature Codes:

- 597103 - BCM PROG, KEYLESS ENTRY REMOTE

## Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Panic_Enable	644	Enable/disable the Panic Mode for the Keyless Remote. A value of 1 enables and a value of 0 disables the feature.	ON	No_Units	N/A	N/A	N/A
Chirp_Enable	647	Enable/disable the remote lock "chirp" for Keyless Remote. A value of 1 enables and a value of 0 disables the feature.	ON	No_Units	N/A	N/A	N/A

## Parameter Definitions:

- **Panic\_Enable** – When this parameter is set to ON. This enables the Panic Mode feature of the keyless remote. The panic function chirps the horn on/off in unison with the headlights and park lights for three minutes when the panic button on the key fob is pressed and the IGN switch is off. If the button is pressed prior to the time out period, the lights and horn will go off.

- **Chirp\_Enable** - When this parameter is set to ON. This enables the Chirp feature for the keyless remote. The chirp feature results in a “chirping” sound when the truck is locked and unlocked.

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
4057699C5	CONTROL, ELECTRONIC, POD PASS DOOR W/RKE
4060791C1	ELECTRONIC, TRANSMITTER, RKE DOOR POD

**Parts Associated with Remote Keyless Entry System**

**Transmitter Learning Process:**

This is the “learning” process for teaching a remote entry transmitter (“Key fob”) to a passenger door pod mounted receiver.

The learning process begins by following the idiosyncratic steps delineate below:

- Step 1 – Simultaneously depress and hold both the lock and unlock buttons located in the passenger door pod.
- Step 2 – With both the lock and unlock buttons depressed, push down and release the passenger door pod’s window control switch actuator at least five times within a time interval of two seconds or less.
- Step 3 – Both lock and unlock buttons (located in the passenger door pod) can be released after completion of step 3.
- Step 4 – Depress any of the five buttons located on the RKE transmitter (Key fob).

**Exiting the Transmitter “Learning” process:**

- The door pod will exit the “learning” process once it enters the sleep state.
- Once the “learning” state has been successfully entered [Step 2] and there is no activity after 30-seconds the passenger door pod will automatically exit the RKE (Key fob) “learn” mode.

**NOTE** - While the passenger door pod is in the “learning” process as many as six RKE (Key fobs) may be “learned” to that single passenger door pod device. Simply depress any of the five buttons on each RKE (Key fob) [Step 4] to “learn” it to the passenger door pod. It is also important to note that while “learning” multiple RKE (Key fobs) to a single passenger door pod device that care is taken to sequentially “learn” the RKE (Key fobs) one at a time so not to confuse the process with multiple RKE (Key fob) transmitters broadcasting differing and simultaneous IP messages to the passenger door pod device.

**How to Test This Feature:**

1. Refer to the applicable feature code using Diamond Logic® Builder programming and diagnostic software to test programmed parameter signal list.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International’s Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**19. Productivity Features****19.1. 08WXB: HEADLIGHT WARNING BUZZER** Sounds When Head Light Switch is on, and Ignition Switch is in “Off” Position.**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** The purpose of the Headlight Warning Buzzer is to alert drivers if their headlights and/or park lights are still on when the vehicle is turned off. This feature can be enabled or disabled by using the Diamond Logic® Builder software.

**Body Controller Software Feature Codes:**

- 597089 – BCM PROG, HEADLIGHT REMINDER #2

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
Exterior_Lamp_Warn	2179	Use this parameter to enable exterior lamp reminder. A value of 1 will result in an audible warning when the vehicle is off, and the lights are on. A value of 0 is used to deactivate the audible warning.	ON	On/Off	0	1	N/A

**Parameter Definitions:**

- **Exterior\_Lamp\_Warn** - Use this parameter to enable exterior lamp reminder. A value of 1 will result in an audible warning when the vehicle is off, and the lights are on. A value of 0 is used to deactivate the audible warning.

**How to Add This Feature:**

Use the Diamond Logic® Builder software to install the appropriate software and determine correct settings for programmable parameters.

**How to Test This Feature:***Exterior\_Lamp\_Warn Disabled:*

1. Turn the key off.
2. Turn headlights on. There should be no warning.

*Exterior\_Lamp\_Warn Enabled:*

1. Turn the key off.
2. Turn headlights on. The warning will beep five times (with the door closed).
3. Open door. The warning will buzz continuously.

**References:**

## Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

## Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

**19.2. 08WXD: ALARM, PARKING BRAKE Electric Horn Sounds in Repetitive Manner when Vehicle Park Brake is “NOT” Set, With Ignition (IGN) “OFF” and any Door Open.****Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** The purpose of the parking brake alarm is to alert drivers if they fail to set the park brake before exiting the vehicle. For this feature to be activated, ALL the following conditions MUST occur:

- The IGN switch is in the off position.
- The parking brake is not set prior to the ignition key being turned to the “OFF” position.
- A cab door is open.

Once activated, the electric horn will sound for 60 seconds, which is the factory default setting for this.

programmable parameter. To deactivate the parking brake alarm, press on the brake pedal to immediately quiet.

the horn, and then make sure the IGN switch is in the run or accessory position and set the park brake.

**Body Controller Software Feature Codes:**

- 597057 – BCM PROG, PARK BRAKE ALARM

### Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
Park_Brake_Alarm_Duration	1951	The amount of time the horn will sound when alarm activated	60	S	0	180	1
Park_Brake_Alarm_Suspend	1952	Amount of time the alarm will suspend before brake is depressed	10	S	0	60	10
Park_Brake_Alarm_KeyOff_Enable	2457	Park brake alarm depends on Key=Off, or not	1	On/Off	0	1	1

### Parameter Definitions:

- **Park\_Brake\_Alarm\_Duration** – This parameter determines the maximum amount of time the horn will sound when the alarm is triggered. The default time is set at 60 seconds, but the range is from 0 to 180-seconds.
- **Park\_Brake\_Alarm\_Suspend** – This parameter determines the amount of time the alarm will suspend after the brake pedal is depressed in order to allow the driver to complete the steps to deactivate the park brake alarm. The default time is set at 10 seconds, but the range is from 0 to 60-seconds.
- **Park\_Brake\_Alarm\_KeyOff\_Enable** – This parameter allows for the selection of the park brake alarm to work in either key off or key on/off.

### How to Test This Feature:

The purpose of the parking brake alarm is to alert drivers if they fail to set the park brake before exiting the vehicle.

For this feature to be activated, ALL the following conditions MUST occur:

- The IGN switch is in the off position.
- The parking brake is not set.
- A cab door is open.

Once activated, the electric horn will sound for 60-seconds, which is the factory default setting for this.

programmable parameter. To deactivate the parking brake alarm, press on the brake pedal to immediately quiet the horn, and then make sure the IGN switch is in the run or accessory position and set the park brake.

### References:

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)


**19.3. 16HCH: SEATBELT WARNING LIGHT IND.** Mounted in Dash, Will Flash when Park Brake is Disengaged and Driver Seatbelt Unfastened, Audible Alarm to Remind Driver to Fasten Seatbelt

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** This feature includes Seat Belt Switches and Seat Sensors for belted positions and a harness routed to the center of the dash for the aftermarket installation of a Data Recorder and Seat Belt Indicator System.

**System Block Diagram:**



**How to Test This Feature:**

Refer to the chassis model circuit diagram manual for diagnostic testing functionality.

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 20. Standard electrical Offerings

**20.1. 08WRB: HEADLIGHTS ON W/WIPERS** Headlights Will Automatically Turn on if Windshield Wipers are turned on. There are two functions, Lights on With Wipers (LOWW) and Day Time Running Lights (DTRL), available with this sales code.

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** Function (LOWW): The Lights On with Wipers (LOWW) function turns on the low beam headlights (tail, marker & clearance lights are also turned on with low beam headlights) whenever the windshield wipers are ON steady or intermittent. The headlights will not be enabled in washer mode. When the wipers are turned OFF, headlights will remain ON until the key is turned OFF or the headlight switch is cycled from OFF to ON to OFF. This feature may be enabled or disabled by using Diamond Logic® Builder programming software.

**Body Controller Software Feature Codes:**

- 597079 – BCM PROG, HEADLIGHT ON W/WIPERS

**How to Test This Feature:**

1. Connect Diamond Logic Builder software to the vehicle to check the parameter box for Lights\_on\_with\_Wipers and program the Body Controller.
2. Turn on the wipers (Steady or Intermittent) and verify that the low beam headlights, tail, marker and/or clearance lights are turned on.
3. Turn off the wipers and verify that the above lights are OFF.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International’s Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 21. Work light Outside Cab Features

**21.1. 08WMA: SWITCH, TOGGLE, FOR WORK LIGHT** Lighted; on Instrument Panel and Wiring Effects for Customer Furnished Back of Cab Light.

**Feature Applicability to Vehicle Platforms:**


- eMV

**Extended Description:** This feature includes a switch in the Instrument Panel (IP). The switch will illuminate when the switch is on. The feature provides an output from the Body Controller (BCM) and provides wiring to the back of cab which includes power and ground. This can be used to satisfy any number of electrical needs such as lights inside dry van boxes, small pumps and illumination to aid in various job functions.

If the key is off, there is a time out parameter, which is factory set at 120-minutes. If the vehicle is running, the work light will not time out. If the work light is left on when the vehicle is

moving, the work light will turn off when the vehicle speed exceeds the work light off speed parameter. This parameter is factory set at 2-MPH. Both parameters can be changed through the Diamond Logic® Builder software.

**System Block Diagram:**



**Body Controller Software Feature Codes:**

- 597008 - BCM PROG, WORK LIGHT Rocker Switch
  - (If there is the desire to turn off the work light feature’s diagnostics each parameter setting will need to be set to zero).

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
Work_Light_Hi_Current	1899	Work Light High Current Detection Level (Amps)	10	A	0	10	0.1
Work_Light_Lo_Current	1898	Work Light Low Current Detection Level (Amps)	0.5	A	0	10	0.1
Work_Light_OC_Current	1900	Work Light Open Circuit Detection Level (Amps)	0.5	A	0	10	0.1
Work_Light_Off_Speed	2568	This parameter is required to turn off the work light if the vehicle’s speed is	2	Mph	1	90	2

		greater than the work light off speed parameter					
Work_Light_Timeout_Enable	640	This parameter sets the amount of time that the work light will remain on after the ignition is turned to off.	2	Hours	0.16	24	0.16

**Parameter Definitions:**

- **Work\_Light\_Hi\_Current** - If the current in the work light circuit exceeds the level set by this parameter, the Body Controller (BCM) will shut off the circuit and register a fault code.
- **Work\_Light\_Lo\_Current** - If the current in the work light circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.
- **Work\_Light\_OC\_Current** - This parameter should be left at its factory default of zero.
- **Work\_Light\_Off\_Speed** – This is a programmable parameter for vehicle speed. Once this value is achieved the body controller will turn off the work light.
- **Work\_Light\_Timeout\_Enable** – This parameter is used to set the amount of time that the customer desires the work light to remain on after the IGN key is turned off. This parameter is for customers who desire to have their work light. time out after a specified length of time so that the light does not drain the battery(s) in case the operator forgets to turn the work light off.



**Arrow Indicates Location of Work Light Connector**

**Parts Associated with This Feature:**

<b>PART NUMBER</b>	<b>DESCRIPTION</b>
<b>MULTIPLEX SWITCH-PACK PARTS</b>	
4057689C1	HOUSING, SWITCH 6-PACK DIN MULTIPLEX
4102405C1	POSITION 3-POSITION MONOSTABLE "MOMENTARY" WORK LIGHT SWITCH ACTUATOR
<b>WORK LIGHT CONNECTOR (CHASSIS HARNESS)</b>	
1661778C1	2-WAY CONNECTOR BODY
1661875C1	WIRE TERMINAL 16-GAUGE
1661874C1	CONNECTOR LOCK
1661872C1	WIRE TERMINAL SEAL 16-GAUGE
<b>WORK LIGHT MATING CONNECTOR (CHASSIS HARNESS)</b>	
3543888C1	2-WAY CONNECTOR BODY
1661874C1	CONNECTOR LOCK
1667742C1	WIRE TERMINAL 16-GUAGE
1661872C1	WIRE TERMINAL SEAL 16-GAUGE
<b>BODY CONTROL MODULE J1/J6 CONNECTOR PARTS</b>	
3598711C1	12-WAY CONNECTOR BODY J1 (1603)
3573833C1	12-WAY CONNECTOR LOCK J1 (1603)
3544878C1	WIRE TERMINAL 12/14-GAUGE J1 (1603)
3544877C1	WIRE TERMINAL 14/16-GAUGE J1 (1603)
3544876C1	WIRE TERMINAL 16/18-GAUGE J1 (1603)
3544875C1	WIRE TERMINAL 18/20-GAUGE J1 (1603)
3544878C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 12-14-GAUGE [GT280]
3544877C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 14/16-GAUGE [GT280]
3544876C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 16/18-GAUGE [GT280]
3544875C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 18/20-GAUGE [GT280]
3544884C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 16/18-GAUGE [GT150]
3544883C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 20/22-GAUGE [GT150]

**Parts Required to Connect to Work Light Cable**

### **How to Test This Feature:**

1. Activate work light switch.
2. Verify that pin G (labeled Work Light) on the Body Controller (BCM) connector (#1603) is providing battery voltage.
3. Verify that the work light (or alternate load) is functioning properly.
4. Turn work light switch OFF.
5. Verify that the work light output goes OFF.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International's Diamond Logic® Builder software (see local dealer if not owned).

### **References:**

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)


## 21.2. 08WTT: SWITCH, TOGGLE, FOR WORK LIGHT Lighted; on Instrument Panel and Wiring Effects for Customer Furnished End of Frame Light

### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** This feature includes a switch in the Instrument Panel (IP) or Light Control Module (LPM). The switch will illuminate when the switch is on. The feature provides an output from the Body Controller (BCM) and provides wiring to the back of frame which includes power and ground. This can be used to satisfy any number of electrical needs such as lights inside dry van boxes, small pumps and illumination to aid in various job functions. If the key is off, there is a time out parameter, which is factory set at 120-minutes. If the vehicle is running, the work light will not time out. If the work light is left on when the vehicle is moving, the work light will turn off when the vehicle speed exceeds the work light off speed parameter. This parameter is factory set at 2-MPH. Both parameters can be changed through the Diamond Logic® Builder software.

### System Block Diagram:



**Body Controller Software Feature Codes:**


- 597008 - BCM PROG, WORK LIGHT Rocker Switch
  - (If there is the desire to turn off the work light feature’s diagnostics each parameter setting will need to be set to zero).

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
Work_Light_Hi_Current	1899	Work Light High Current Detection Level (Amps)	10	A	0	10	0.1
Work_Light_Lo_Current	1898	Work Light Low Current Detection Level (Amps)	0.5	A	0	10	0.1
Work_Light_OC_Current	1900	Work Light Open Circuit Detection Level (Amps)	0.5	A	0	10	0.1
Work_Light_Off_Speed	2568	This parameter is required to turn off the work light if the vehicle’s speed is greater than the work light off speed parameter	2	Mph	1	90	2
Work_Light_Timeout_Enable	640	This parameter sets the amount of time that the work light will remain on after the ignition is turned off.	2	Hours	0.16	24	0.16

**Parameter Definitions:**

- **Work\_Light\_Hi\_Current** - If the current in the work light circuit exceeds the level set by this parameter, the Body Controller (BCM) will shut off the circuit and register a fault code.
- **Work\_Light\_Lo\_Current** - If the current in the work light circuit falls below the level set by this parameter, the Body Controller (BCM) will register a fault code.
- **Work\_Light\_OC\_Current** - This parameter should be left at its factory default of zero.
- **Work\_Light\_Off\_Speed** – This is a programmable parameter for vehicle speed. Once this value is achieved the body controller will turn off the work light.
- **Work\_Light\_Timeout\_Enable** – This parameter is used to set the amount of time that the customer desires the work light to remain on after the IGN key is turned off. This parameter is for customers who desire to have their work light. time out after a specified length of time so that the light does not drain the battery(s) in case the operator forgets to turn the work light off.



**Arrow Indicates Location of Work Light Connector**

**Parts Associated with This Feature:**

<b>PART NUMBER</b>	<b>DESCRIPTION</b>
<b>MULTIPLEX SWITCH-PACK PARTS</b>	
4057689C1	HOUSING, SWITCH 6-PACK DIN MULTIPLEX
4102405C1	POSITION 3-POSITION MONOSTABLE "MOMENTARY" WORK LIGHT SWITCH ACTUATOR
<b>WORK LIGHT CONNECTOR (CHASSIS HARNESS)</b>	
1661778C1	2-WAY CONNECTOR BODY
1661875C1	WIRE TERMINAL 16-GAUGE
1661874C1	CONNECTOR LOCK
1661872C1	WIRE TERMINAL SEAL 16-GAUGE
<b>WORK LIGHT MATING CONNECTOR (CHASSIS HARNESS)</b>	
3543888C1	2-WAY CONNECTOR BODY
1661874C1	CONNECTOR LOCK
1667742C1	WIRE TERMINAL 16-GUAGE
1661872C1	WIRE TERMINAL SEAL 16-GAUGE
<b>BODY CONTROL MODULE J1/J6 CONNECTOR PARTS</b>	
3598711C1	12-WAY CONNECTOR BODY J1 (1603)
3573833C1	12-WAY CONNECTOR LOCK J1 (1603)
3544878C1	WIRE TERMINAL 12/14-GAUGE J1 (1603)
3544877C1	WIRE TERMINAL 14/16-GAUGE J1 (1603)
3544876C1	WIRE TERMINAL 16/18-GAUGE J1 (1603)
3544875C1	WIRE TERMINAL 18/20-GAUGE J1 (1603)

3544878C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 12-14-GAUGE [GT280]
3544877C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 14/16-GAUGE [GT280]
3544876C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 16/18-GAUGE [GT280]
3544875C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 18/20-GAUGE [GT280]
3544884C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 16/18-GAUGE [GT150]
3544883C1	18-WAY BODY CONTROLLER J6 (1606/2023) CONNECTOR WIRE TERMINAL 20/22-GAUGE [GT150]

### Parts Required to Connect to Work Light Cable

#### How to Test This Feature:

1. Activate work light switch.
2. Verify that pin G (labeled Work Light) on the Body Controller (BCM) connector (#1603) is providing battery voltage.
3. Verify that the work light (or alternate load) is functioning properly.
4. Turn work light switch OFF.
5. Verify that the work light output goes OFF.

**NOTE** - This feature uses body controller-based software controls which can be diagnosed with International's Diamond Logic® Builder software (see local dealer if not owned).

#### References:

Circuit Diagram Manual:

Publication Number: 0000018831 – International eMV Series Interactive Schematics

Service Manual:

Publication Number: 0001253563 – 2021 International eMV Technician Manual (Service and Diagnostic)

## 22. Body Builder Integration Harnesses

**22.1. 08XMB:** WIRING (1)TMC RP1226 BEHIND CTR CONSOLE CONNECTOR, DASH, CENTER PANEL Cab Wiring for TMC RP1226 Vehicle Accessory Connector; Includes 14-pin Connector with Switched Power, Battery Power, Ignition Power, Ground & Body 250K Datalink, Connector Located Behind Instrument Panel Center Console


#### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** This feature provides a connector that provides battery, ignition, ground and connections to the 250K Baud Body Builder data link.

RP1226 is a "recommended practice" from the 2015 TMC (the ATA's Technology and Maintenance Council). It is a new way for telematics providers to connect to the vehicle. It is a standardized connector for telematics devices to plug into heavy duty vehicles as an alternative to the 9-pin diagnostic connector.

**System Block Diagram:**




**Parts Associated with This Feature:**


PART NUMBERS	DESCRIPTION
<b>08XMB CONNECTOR (OEM CONNECTOR BODY)</b>	
6114576C1	14-WAY CONNECTOR BODY
3989901C1	WIRE TERMINAL 14-GAUGE
3753255C1	WIRE TERMINAL 12-GAUGE
<b>08XMB CONNECTOR (MALE CONNECTOR BODY)</b>	
6114577C1	14-WAY CONNECTOR BODY
3626441C1	WIRE TERMINAL 20-18 GAUGE
3627568C1	WIRE TERMINAL 16-14 GAUGE

**Parts Associated with 08XMB Feature.**

**Connector Location:**



### Connector Pin Outs:



### References:

Refer to the applicable International® Circuit Diagrams and Service Manuals.

**22.2. 08XMZ:** WIRING (2)TMC RP1226 BEHIND CTR CONSOLECONNECTOR, DASH, CENTER PANEL Cab Wiring for (2) TMC RP1226 Vehicle Accessory Connectors; Includes (2) 14-pin Connectors with Switched Power, Battery Power, Ignition Power, Ground & Body 250K Datalink, Connector Located Behind Instrument Panel Center Console

### Feature Applicability to Vehicle Platforms:


- eMV

**Extended Description:** This feature provides a connector that provides battery, ignition, ground and connections to the 250K Baud Body Builder data link.

RP1226 is a "recommended practice" from the 2015 TMC (the ATA's Technology and Maintenance Council). It is a new way for telematics providers to connect to the vehicle.

It is a standardized connector for telematics devices to plug into heavy duty vehicles as an alternative to the 9-pin diagnostic connector.

**System Block Diagram:**




**Parts Associated with This Feature:**


PART NUMBERS	DESCRIPTION
<b>08XMZ CONNECTOR (OEM CONNECTOR BODY)</b>	
6114576C1	14-WAY CONNECTOR BODY
3989901C1	WIRE TERMINAL 14-GAUGE
3753255C1	WIRE TERMINAL 12-GAUGE
<b>08XMZ CONNECTOR (MALE CONNECTOR BODY)</b>	
6114577C1	14-WAY CONNECTOR BODY
3626441C1	WIRE TERMINAL 20-18 GAUGE
3627568C1	WIRE TERMINAL 16-14 GAUGE

**Parts Associated with 08XMZ Feature**


**Connector Location:**



**Connector Pin Outs:**



Pin	Value
2	J1939 250 K (+) Body Builder
7	Ignition Power
8	Ground
9	J1939 250K (-) Body Builder
14	Battery Power



**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals.

**22.3. 08XNA, CENTER PANEL Cab Wiring for (3) TMC RP1226 Vehicle Accessory Connectors;**  
 Includes (3) 14-pin Connectors with Switched Power, Battery Power, Ignition Power, Ground &  
 Body 250K Datalink, Connector Located Behind Instrument Panel Center Console

**Feature Applicability to Vehicle Platforms:**


- eMV

**Extended Description:** This feature provides a connector that provides battery, ignition, ground and connections to the 250K Baud Body Builder data link.

RP1226 is a "recommended practice" from the 2015 TMC (the ATA's Technology and Maintenance Council). It is a new way for telematics providers to connect to the vehicle.

It is a standardized connector for telematics devices to plug into heavy duty vehicles as an alternative to the 9-pin diagnostic connector.

**System Block Diagram:**




**Parts Associated with This Feature:**


PART NUMBERS	DESCRIPTION
<b>08XNA CONNECTOR (OEM CONNECTOR BODY)</b>	
6114576C1	14-WAY CONNECTOR BODY
3989901C1	WIRE TERMINAL 14-GAUGE
3753255C1	WIRE TERMINAL 12-GAUGE
<b>08XNA CONNECTOR (MALE CONNECTOR BODY)</b>	
6114577C1	14-WAY CONNECTOR BODY
3626441C1	WIRE TERMINAL 20-18 GAUGE
3627568C1	WIRE TERMINAL 16-14 GAUGE

**Parts Associated with 08XNA Feature**


**Connector Location:**



### Connector Pin Outs:



Pin	Value
2	J1939 250 K (+) Body Builder
7	Ignition Power
8	Ground
9	J1939 250K (-) Body Builder
14	Battery Power



### References:

Refer to the applicable International® Circuit Diagrams and Service Manuals.

## 23. Power Features using Remote Power Modules

These features are not available for order from the plant but can be added after delivery.


### 23.1. 60AAG: BDY INTG, REMOTE POWER MODULE Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs, Max 20 amp per Channel, Max 80 amp Total; Includes 1 Switch Pack with Latched Switches

#### Feature Applicability to Vehicle Platforms:

- eMV

**Extended Description:** Feature 60AAG includes one Remote Power Module (RPM) mounted behind the passenger seat on eMV models. Included with this feature are six two-position latched switches located in the Instrument Panel. Each RPM output can provide up to 20-Amps maximum with a total of 80-Amps maximum per module.

#### System Block Diagram:



#### Body Controller Software Feature Codes:

Note: Feature code 60AJL is configured by special unadvertised software feature codes. These codes are determined by the number of additional features that use the RPM resources. The following codes should be added after all other features are added to the vehicle.

60ACA = 597194 – This feature should be added if there are features already using five RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD #1)

60ACB = 597195 – This feature should be added if there are features already using four RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 2 ROCKER SW)  
60ACC = 597196 – This feature should be added if there are features already using three RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 3 ROCKER SW)  
60ACD = 597197 – This feature should be added if there are features already using two RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 4 ROCKER SW)  
60ACJ = 597198 – This feature should be added if there are features already using one RPM input/output. (BCM PROG, AUXILIARY LOAD 5 ROCKER SW)  
60ACK = 597199 – This feature should be added if there no other features using any RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 6 ROCKER SW)

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
<b>597194 - BCM PROG, AUXILIARY LOAD #1 For Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
<b>597195 - BCM PROG, AUXILIARY LOAD For (2) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
<b>597196 - BCM PROG, AUXILIARY LOAD For (3) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
<b>597197 - BCM PROG, AUXILIARY LOAD For (4) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1

TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
<b>597198 - BCM PROG, AUXILIARY LOAD For (5) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
<b>597199 - BCM PROG, AUXILIARY LOAD For (6) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1

TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux6_Output_Fuse_Param	2000	This is the maximum current Aux 6 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
TEM_Aux6_Loadshed_Level	3278	Load shed level parameter for TEM Aux Switch 6	1	No Units	0	3	1

### Parameter Definitions:

- **TEM\_Aux1\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_1\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux2\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_2\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux3\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_3\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux4\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_4\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux5\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_5\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux6\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_6\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux1\_LoadShed\_Level** – This is the level at which the Aux1 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux2\_LoadShed\_Level** – This is the level at which the Aux2 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

- **TEM\_Aux3\_LoadShed\_Level** – This is the level at which the Aux3 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux4\_LoadShed\_Level** – This is the level at which the Aux4 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux5\_LoadShed\_Level** – This is the level at which the Aux5 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux6\_LoadShed\_Level** – This is the level at which the Aux6 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
3766091C1	SWITCH, ELECTRONIC, BLANK WINDOW ROCKER - 3 POS - MONOSTABLE
4057689C2	HOUSING, SWITCH*6-PACK DIN MULT
2585423C91	KIT, RPM TERMINAL/SEAL 14GA
2585651C91	KIT, RPM TERMINAL/SEAL 12GA
2588909C92	RPM BY ITSELF
3519178C91	RESISTOR, ELECT TERMINATING

**Switches, RPM, Output Terminal Part Numbers**

**How to Test This Feature:**

1. Turn key to accessory or IGN key-state.
2. Activate first in-cab switch.
3. Verify that RPM output #1 is providing battery voltage.
4. Deactivate first in-cab switch.
5. Apply 12V to RPM input #1.
6. Verify that RPM output #1 is providing battery voltage.
7. Apply GND to RPM input #1.
8. Verify that RPM output #1 shuts off.

Continue the above testing procedure for each RPM switch location.

Note: This feature uses body controller-based software controls which can be diagnosed with The International® Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals.


**23.2. 60AAH: BDY INTG, REMOTE POWER MODULE (2) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 2 Switch Packs with Latched Switches.**

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** Feature 60AAH includes two Remote Power Modules (RPMs) mounted behind the passenger seat on eMV models. Included with this feature are twelve two-position latched switches located in the Instrument Panel. Each RPM output is capable of providing up to 20-Amps maximum with a total of 80-Amps maximum per module.

**System Block Diagram:**



**Body Controller Software Feature Codes:**

Note: Feature code 60AJM is configured by special unadvertised software feature codes. These codes are determined by the number of additional features that use the RPM resources. The following codes should be added after all other features are added to the vehicle.

60ACA = 597194 – This feature should be added if there are features already using five RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD #1)

60ACB = 597195 – This feature should be added if there are features already using four RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 2 ROCKER SW)

60ACC = 597196 – This feature should be added if there are features already using three RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 3 ROCKER SW)

60ACD = 597197 – This feature should be added if there are features already using two RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 4 ROCKER SW)

60ACJ = 597198 – This feature should be added if there are features already using one RPM input/output. (BCM PROG, AUXILIARY LOAD 5 ROCKER SW)

60ACK = 597199 – This feature should be added if there no other features using any RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 6 ROCKER SW)

60ACV = 597202 – This feature should be added to add the second RPM (60AAB). (BCM PROG, ADDITIONAL 6 AUXILIARY SW)

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
<b>597194 - BCM PROG, AUXILIARY LOAD #1 For Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
<b>597195 - BCM PROG, AUXILIARY LOAD For (2) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
<b>597196 - BCM PROG, AUXILIARY LOAD For (3) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
<b>597197 - BCM PROG, AUXILIARY LOAD For (4) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1

TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
<b>597198 - BCM PROG, AUXILIARY LOAD For (5) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
<b>597199 - BCM PROG, AUXILIARY LOAD For (6) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux6_Output_Fuse_Param	2000	This is the maximum current Aux 6 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1

TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
TEM_Aux6_Loadshed_Level	3278	Load shed level parameter for TEM Aux Switch 6	1	No Units	0	3	1
<b>597202 – BCM PROG, ADDITIONAL 6 AUXILIARY SW</b>							
TEM_Aux7_Output_Fuse_Param	2100	This is the maximum current Aux 7 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux8_Output_Fuse_Param	2101	This is the maximum current Aux 8 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux9_Output_Fuse_Param	2102	This is the maximum current Aux 9 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux10_Output_Fuse_Param	2103	This is the maximum current Aux 10 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux11_Output_Fuse_Param	2104	This is the maximum current Aux 11 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux12_Output_Fuse_Param	2105	This is the maximum current Aux 12 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux7_Loadshed_Level	3339	Load shed level parameter for TEM Aux Switch 7	1	No Units	0	3	1
TEM_Aux8_Loadshed_Level	3340	Load shed level parameter for TEM Aux Switch 8	1	No Units	0	3	1
TEM_Aux9_Loadshed_Level	3341	Load shed level parameter for TEM Aux Switch 9	1	No Units	0	3	1
TEM_Aux10_Loadshed_Level	3342	Load shed level parameter for TEM Aux Switch 10	1	No Units	0	3	1
TEM_Aux11_Loadshed_Level	3343	Load shed level parameter for TEM Aux Switch 11	1	No Units	0	3	1
TEM_Aux12_Loadshed_Level	3344	Load shed level parameter for TEM Aux Switch 12	1	No Units	0	3	1

### Parameter Definitions:

- **TEM\_Aux1\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_1\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux2\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_2\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux3\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_3\_Output of RPM #1. Default is set at 20 amps.

- **TEM\_Aux4\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_4\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux5\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_5\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux6\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_6\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux7\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_7\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux8\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_8\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux9\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_9\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux10\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_10\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux11\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_11\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux12\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_12\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux1\_LoadShed\_Level** – This is the level at which the Aux1 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux2\_LoadShed\_Level** – This is the level at which the Aux2 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux3\_LoadShed\_Level** – This is the level at which the Aux3 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux4\_LoadShed\_Level** – This is the level at which the Aux4 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux5\_LoadShed\_Level** – This is the level at which the Aux5 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

- **TEM\_Aux6\_LoadShed\_Level** – This is the level at which the Aux6 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux7\_LoadShed\_Level** – This is the level at which the Aux7 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux8\_LoadShed\_Level** – This is the level at which the Aux8 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux9\_LoadShed\_Level** – This is the level at which the Aux9 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux10\_LoadShed\_Level** – This is the level at which the Aux10 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux11\_LoadShed\_Level** – This is the level at which the Aux11 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux12\_LoadShed\_Level** – This is the level at which the Aux12 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
3766092C1	SWITCH, ELECTRONIC, BLANK WINDOW ROCKER - 2 POS - BISTABLE
4057689C2	HOUSING, SWITCH*6-PACK DIN MULT
2585423C91	KIT, RPM TERMINAL/SEAL 14GA
2585651C91	KIT, RPM TERMINAL/SEAL 12GA
2588909C92	RPM BY ITSELF
3519178C91	RESISTOR, ELECT TERMINATING

**Switches, RPM, Output Terminal Part Numbers**

**How to Test This Feature:**

1. Turn key to accessory or IGN key-state.
  2. Activate first in-cab switch.
  3. Verify that RPM output #1 is providing battery voltage.
  4. Deactivate first in-cab switch.
  5. Apply 12V to RPM input #1.
  6. Verify that RPM output #1 is providing battery voltage.
  7. Apply GND to RPM input #1.
  8. Verify that RPM output #1 shuts off.
- Continue the above testing procedure for each RPM switch location.

Note: This feature uses body controller-based software controls which can be diagnosed with The International® Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals.


**23.3. 60AAJ: DY INTG, REMOTE POWER MODULE (3) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 3 switch Packs with Latched Switches.**

**Feature Applicability to Vehicle Platforms:**

- eMV

**Extended Description:** Feature 60AAJ Includes eighteen two-position latched switches located in the Instrument Panel. Each RPM output is capable of providing up to 20-Amps maximum with a total of 80-Amps maximum per module.

**System Block Diagram:**



**Body Controller Software Feature Codes:**

Note: Feature code 60AJM is configured by special unadvertised software feature codes. These codes are determined by the number of additional features that use the RPM resources. The following codes should be added after all other features are added to the vehicle.

60ACA = 597194 – This feature should be added if there are features already using five RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD #1)

60ACB = 597195 – This feature should be added if there are features already using four RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 2 ROCKER SW)

60ACC = 597196 – This feature should be added if there are features already using three RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 3 ROCKER SW)

60ACD = 597197 – This feature should be added if there are features already using two RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 4 ROCKER SW)

60ACJ = 597198 – This feature should be added if there are features already using one RPM input/output. (BCM PROG, AUXILIARY LOAD 5 ROCKER SW)

60ACK = 597199 – This feature should be added if there no other features using any RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 6 ROCKER SW)

60ACV = 597202 – This feature should be added to add the second RPM (60AAB). (BCM PROG, ADDITIONAL 6 AUXILIARY SW)

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
<b>597194 - BCM PROG, AUXILIARY LOAD #1 For Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
<b>597195 - BCM PROG, AUXILIARY LOAD For (2) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
<b>597196 - BCM PROG, AUXILIARY LOAD For (3) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1

TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
<b>597197 - BCM PROG, AUXILIARY LOAD For (4) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
<b>597198 - BCM PROG, AUXILIARY LOAD For (5) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
<b>597199 - BCM PROG, AUXILIARY LOAD For (6) Rocker Switch</b>							

TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux6_Output_Fuse_Param	2000	This is the maximum current Aux 6 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
TEM_Aux6_Loadshed_Level	3278	Load shed level parameter for TEM Aux Switch 6	1	No Units	0	3	1
<b>597202 – BCM PROG, ADDITIONAL 6 AUXILIARY SW</b>							
TEM_Aux7_Output_Fuse_Param	2100	This is the maximum current Aux 7 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux8_Output_Fuse_Param	2101	This is the maximum current Aux 8 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux9_Output_Fuse_Param	2102	This is the maximum current Aux 9 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux10_Output_Fuse_Param	2103	This is the maximum current Aux 10 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux11_Output_Fuse_Param	2104	This is the maximum current Aux 11 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux12_Output_Fuse_Param	2105	This is the maximum current Aux 12 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux7_Loadshed_Level	3339	Load shed level parameter for TEM Aux Switch 7	1	No Units	0	3	1
TEM_Aux8_Loadshed_Level	3340	Load shed level parameter for TEM Aux Switch 8	1	No Units	0	3	1
TEM_Aux9_Loadshed_Level	3341	Load shed level parameter for TEM Aux Switch 9	1	No Units	0	3	1
TEM_Aux10_Loadshed_Level	3342	Load shed level parameter for TEM Aux Switch 10	1	No Units	0	3	1

TEM_Aux11_Loadshed_Level	3343	Load shed level parameter for TEM Aux Switch 11	1	No Units	0	3	1
TEM_Aux12_Loadshed_Level	3344	Load shed level parameter for TEM Aux Switch 12	1	No Units	0	3	1

### Parameter Definitions:

- **TEM\_Aux1\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_1\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux2\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_2\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux3\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_3\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux4\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_4\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux5\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_5\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux6\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_6\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux7\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_7\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux8\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_8\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux9\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_9\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux10\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_10\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux11\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_11\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux12\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_12\_Output of RPM #2. Default is set at 20 amps.

- **TEM\_Aux1\_LoadShed\_Level** – This is the level at which the Aux1 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux2\_LoadShed\_Level** – This is the level at which the Aux2 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux3\_LoadShed\_Level** – This is the level at which the Aux3 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux4\_LoadShed\_Level** – This is the level at which the Aux4 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux5\_LoadShed\_Level** – This is the level at which the Aux5 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux6\_LoadShed\_Level** – This is the level at which the Aux6 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux7\_LoadShed\_Level** – This is the level at which the Aux7 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux8\_LoadShed\_Level** – This is the level at which the Aux8 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux9\_LoadShed\_Level** – This is the level at which the Aux9 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux10\_LoadShed\_Level** – This is the level at which the Aux10 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux11\_LoadShed\_Level** – This is the level at which the Aux11 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux12\_LoadShed\_Level** – This is the level at which the Aux12 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
3766092C1	SWITCH, ELECTRONIC, BLANK WINDOW ROCKER - 2 POS - BISTABLE
4057689C2	HOUSING, SWITCH*6-PACK DIN MULT
2585423C91	KIT, RPM TERMINAL/SEAL 14GA
2585651C91	KIT, RPM TERMINAL/SEAL 12GA
2588909C92	RPM BY ITSELF
3519178C91	RESISTOR, ELECT TERMINATING

**Switches, RPM, Output Terminal Part Numbers****How to Test This Feature:**

1. Turn key to accessory or IGN key-state.
2. Activate first in-cab switch.
3. Verify that RPM output #1 is providing battery voltage.
4. Deactivate first in-cab switch.
5. Apply 12V to RPM input #1.
6. Verify that RPM output #1 is providing battery voltage.
7. Apply GND to RPM input #1.
8. Verify that RPM output #1 shuts off.

Continue the above testing procedure for each RPM switch location.

Note: This feature uses body controller-based software controls which can be diagnosed with The International® Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals


**23.4. 60AAP: BDY INTG, REMOTE POWER MODULE (3) Mounted Inside Cab Behind Driver Seat, Up to 6 Outputs & 6 Inputs Each, Max 20 amp per Channel, Max 80 amp Total; Includes 2 Modules with Switch Packs Containing 6 Latched Switches, 1 Module with Hardware Only**

**Feature Applicability to Vehicle Platforms:**

- eMV

Extended Description: Feature 60AAP Includes twelve two-position latched switches located in the Instrument Panel. Each RPM output is capable of providing up to 20-Amps maximum with a total of 80-Amps maximum per module. 1 Module with Hardware Only

**System Block Diagram:**



**Body Controller Software Feature Codes:**

Note: Feature code 60AJM is configured by special unadvertised software feature codes. These codes are determined by the number of additional features that use the RPM resources. The following codes should be added after all other features are added to the vehicle.

60ACA = 597194 – This feature should be added if there are features already using five RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD #1)

60ACB = 597195 – This feature should be added if there are features already using four RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 2 ROCKER SW)

60ACC = 597196 – This feature should be added if there are features already using three RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 3 ROCKER SW)

60ACD = 597197 – This feature should be added if there are features already using two RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 4 ROCKER SW)

60ACJ = 597198 – This feature should be added if there are features already using one RPM input/output. (BCM PROG, AUXILIARY LOAD 5 ROCKER SW)

60ACK = 597199 – This feature should be added if there no other features using any RPM inputs/outputs. (BCM PROG, AUXILIARY LOAD 6 ROCKER SW)

60ACV = 597202 – This feature should be added to add the second RPM (60AAB). (BCM PROG, ADDITIONAL 6 AUXILIARY SW)

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
<b>597194 - BCM PROG, AUXILIARY LOAD #1 For Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
<b>597195 - BCM PROG, AUXILIARY LOAD For (2) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
<b>597196 - BCM PROG, AUXILIARY LOAD For (3) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1

TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
<b>597197 - BCM PROG, AUXILIARY LOAD For (4) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
<b>597198 - BCM PROG, AUXILIARY LOAD For (5) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
<b>597199 - BCM PROG, AUXILIARY LOAD For (6) Rocker Switch</b>							
TEM_Aux1_Output_Fuse_Param	1990	This is the maximum current Aux 1 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux2_Output_Fuse_Param	1991	This is the maximum current Aux 2 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1

TEM_Aux3_Output_Fuse_Param	1992	This is the maximum current Aux 3 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux4_Output_Fuse_Param	1995	This is the maximum current Aux 4 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux5_Output_Fuse_Param	1999	This is the maximum current Aux 5 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux6_Output_Fuse_Param	2000	This is the maximum current Aux 6 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux1_Loadshed_Level	3273	Load shed level parameter for TEM Aux Switch 1	1	No Units	0	3	1
TEM_Aux2_Loadshed_Level	3274	Load shed level parameter for TEM Aux Switch 2	1	No Units	0	3	1
TEM_Aux3_Loadshed_Level	3275	Load shed level parameter for TEM Aux Switch 3	1	No Units	0	3	1
TEM_Aux4_Loadshed_Level	3276	Load shed level parameter for TEM Aux Switch 4	1	No Units	0	3	1
TEM_Aux5_Loadshed_Level	3277	Load shed level parameter for TEM Aux Switch 5	1	No Units	0	3	1
TEM_Aux6_Loadshed_Level	3278	Load shed level parameter for TEM Aux Switch 6	1	No Units	0	3	1
<b>597202 – BCM PROG, ADDITIONAL 6 AUXILIARY SW</b>							
TEM_Aux7_Output_Fuse_Param	2100	This is the maximum current Aux 7 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux8_Output_Fuse_Param	2101	This is the maximum current Aux 8 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux9_Output_Fuse_Param	2102	This is the maximum current Aux 9 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux10_Output_Fuse_Param	2103	This is the maximum current Aux 10 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux11_Output_Fuse_Param	2104	This is the maximum current Aux 11 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux12_Output_Fuse_Param	2105	This is the maximum current Aux 12 Output is allowed to source before the virtual fusing turns the output off.	20	A	0	20	0.1
TEM_Aux7_Loadshed_Level	3339	Load shed level parameter for TEM Aux Switch 7	1	No Units	0	3	1
TEM_Aux8_Loadshed_Level	3340	Load shed level parameter for TEM Aux Switch 8	1	No Units	0	3	1
TEM_Aux9_Loadshed_Level	3341	Load shed level parameter for TEM Aux Switch 9	1	No Units	0	3	1
TEM_Aux10_Loadshed_Level	3342	Load shed level parameter for TEM Aux Switch 10	1	No Units	0	3	1
TEM_Aux11_Loadshed_Level	3343	Load shed level parameter for TEM Aux Switch 11	1	No Units	0	3	1
TEM_Aux12_Loadshed_Level	3344	Load shed level parameter for TEM Aux Switch 12	1	No Units	0	3	1

## Parameter Definitions:

- **TEM\_Aux1\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_1\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux2\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_2\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux3\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_3\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux4\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_4\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux5\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_5\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux6\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_6\_Output of RPM #1. Default is set at 20 amps.
- **TEM\_Aux7\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_7\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux8\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_8\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux9\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_9\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux10\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_10\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux11\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_11\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux12\_Output\_Fuse\_Param** – This parameter sets the limit (in AMPS) of the current flowing from the output labeled Aux\_Switch\_12\_Output of RPM #2. Default is set at 20 amps.
- **TEM\_Aux1\_LoadShed\_Level** – This is the level at which the Aux1 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

- **TEM\_Aux2\_LoadShed\_Level** – This is the level at which the Aux2 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux3\_LoadShed\_Level** – This is the level at which the Aux3 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux4\_LoadShed\_Level** – This is the level at which the Aux4 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux5\_LoadShed\_Level** – This is the level at which the Aux5 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux6\_LoadShed\_Level** – This is the level at which the Aux6 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux7\_LoadShed\_Level** – This is the level at which the Aux7 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux8\_LoadShed\_Level** – This is the level at which the Aux8 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux9\_LoadShed\_Level** – This is the level at which the Aux9 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux10\_LoadShed\_Level** – This is the level at which the Aux10 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux11\_LoadShed\_Level** – This is the level at which the Aux11 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).
- **TEM\_Aux12\_LoadShed\_Level** – This is the level at which the Aux12 Output will load shed. A value of ZERO (0) disables load shed. A value of ONE (1) is least priority (sheds first), a value of 3 highest priority (sheds last).

**Parts Associated with This Feature:**

PART NUMBER	DESCRIPTION
3766092C1	SWITCH, ELECTRONIC, BLANK WINDOW ROCKER - 2 POS - BISTABLE
4057689C2	HOUSING, SWITCH*6-PACK DIN MULT
2585423C91	KIT, RPM TERMINAL/SEAL 14GA
2585651C91	KIT, RPM TERMINAL/SEAL 12GA
2588909C92	RPM BY ITSELF
3519178C91	RESISTOR, ELECT TERMINATING

**Switches, RPM, Output Terminal Part Numbers****How to Test This Feature:**

1. Turn key to accessory or IGN key-state.
2. Activate first in-cab switch.
3. Verify that RPM output #1 is providing battery voltage.
4. Deactivate first in-cab switch.
5. Apply 12V to RPM input #1.
6. Verify that RPM output #1 is providing battery voltage.
7. Apply GND to RPM input #1.
8. Verify that RPM output #1 shuts off.

Continue the above testing procedure for each RPM switch location.

Note: This feature uses body controller-based software controls which can be diagnosed with The International® Diamond Logic® Builder software (see local dealer if not owned).

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals.

## 24. ePTO

**WARNING** – To avoid serious personal injury, possible death, or damage to the vehicle, when servicing the HVDM connection, Level 2 isolation is required. Ensure that only trained personnel using the appropriate procedures and safety equipment are working on these connections. Course information can be found at the [International Motors - Learning](#) website.


**08PAA: HIGH VOLTAGE POWER ACCESSORY 40kW Electronic Power Take Off, with SAE B Pump Flange, Mounted Left Side Under Cab**

Note: 08PAA only offered with a single 12 volt battery. If configuration requires additional capacity, consult Application Engineering. Always take actions to prevent draining the batteries with parasitic loads.

### Feature Applicability to Vehicle Platforms:

- Electric Vehicle (eMV)

**Extended Description:** This feature provides a factory installed motor and inverter for TEM integration of hydraulic and other pump systems. HV connection and cooling are factory installed as well.




PTO Motor Location in Battery Box

**Caution** – At initial setup, the motor direction should be verified before installing the pump to avoid blowing out seals.

The PTO is enabled by a switch in the switch 6 pack. The PTO speed can be controlled by the cruise switches or by remote connections to the 12 pin body builder connector.

The 12 pin connector, located under the hood, has circuits for requesting preset speed control, variable speed control and remote pedal speed control. It also has circuits that provide data link connection to allow a 3rd Party controller device to be used.


**Body Builder Low Voltage Connection:** The ePTO 12-pin Body Builder Connector is located under the hood approximately 18” from PDM2. This connection comes with a factory installed cap that includes a terminating resistor. Remove cap and connect TEM controller CAN wires to pin 5 (CANH) and pin 6 (CANL). Maintain/Re-install terminating resistor.



Connector Pinout

12 pin connector	Signal Name	VCU Pin
Pin 1	Remote PTO ON/OFF Switch	Pin 33
Pin 2	Cruise Control/PTO Resume Switch	Pin 44
Pin 3	Remote Accelerator On/Off Switch	Pin 30
Pin 4	Cruise Control/PTO Set Switch	Pin 45
Pin 5	CAN High	N.C.
Pin 6	CAN Low	N.C.
Pin 7	DI_GND	Pin 79
Pin 8	5V Supply	Pin 71
Pin 9	Control PTO ON/OFF Switch	Pin 32
Pin 10	Signal Return	Pin 47
Pin 11	DI_EPTO_E_STOP	Pin 58
Pin 12	Remote Accelerator Pedal Signal	Pin 41

### 6095 Connector Pins to VCU Pins



Wiring Suggestions

### Parts Associated with This Feature:

PART NUMBER	DESCRIPTION
EPTO BODY BUILDER 6095F	
3586750C1	CONNECTOR
3553460C1	CONNECTOR LOCK
3727971C1	TERMINAL
EPTO BODY BUILDER CAP 6095M	
3838727C1	CONNECTOR
3589992C1	CONNECTOR LOCK
3518961C1	TERMINAL
CAN BODY BUS RESISTOR 6096	
4173578C1	CAN BODY BUS RESISTOR
3573833C1	CONNECTOR LOCK
3683466C1	CONNECTOR LOCK
3769112C91	J1939 120 OHM 1 WATT RESISTOR

### Parts Associated with Feature

**ePTO High Voltage Connection:** The PTO high voltage connection is provided at a connector on the high Voltage distribution module (HVDM)


**ePTO**

The factory-installed ePTO is ready to power your boom, crane, bucket and more. Quiet, electric power offers a variety of benefits, including the ability of operators in the bucket to easily communicate with those on the ground.



**ePTO Electrical System**  
Single connection

- High voltage - \*210 kWh Lithium Iron Phosphate batteries with dedicated HVAC system
- 609V nominal operating voltage
- Amphenol PowerLok Gen2
- Typical applications: Utility, Dump

- 40 kW\* Minimum Continuous Power Operation
- 60 kW Maximum Peak Power Operation



Single Connector




\*Assumes 3,000 rpm hydraulic system limit.  
\*Useable capacity is approx. 189 kWh. Actual range is based on environmental conditions, driving behaviors, etc.

Note: The information and conclusions contained herein are believed to be correct at time of publication, but do not necessarily apply to similar vehicles with different specifications or with production dates after the production of this publication. Vehicles with different specifications or later dates of production may yield different results. Vehicles specifications are subject to change without notice. TAD23005 09/2024 \*2024 International Motors, LLC. All rights reserved. All marks are trademarks of their respective owners.



**System Block Diagram:**



**Programming Tools Required:**

- Diamond Logic Builder (DLB)
- Service Diagnostics Solutions (SDS)

**Body Controller Software Feature Codes:**

- 0597737 BCM PROG, ELECT POWER TAKE OFF Use with High Voltage Power Accessory for Electric Vehicles
- 0597755 BCM PROG, ePTO MONITOR INDICATOR & ALARM

**Body Controller Software Feature Code Parameters:**

Parameter	ID	Description	Default	Units	Min	Max	Step
PTO_Engagement_Status_Signal_Delay	3633	Parameter for the debounce of the PTO Engagement status message from TCM	100	ms	100	500	100
PTO_Veh_Spd_Threshold	3659	Parameter sets the vehicle speed at which the PTO will not be engaged if the threshold is exceeded.	3	mph	1	100	1

HV_SOC_CityHorn_Warning_Duration	3762	Duration of State-of-Charge City Horn Warning Pattern	3	s	0	10	1
HV_SOC_Level_1_Timer_Threshold	3767	HV_SOC_Level_1_Timer_Threshold	5	s	0	3600	1
HV_SOC_Level_2_Timer_Threshold	3765	HV_SOC_Level_2_Timer_Threshold	10	s	0	3600	1
HV_SOC_Level_3_Timer_Threshold	3763	HV_SOC_Level_3_Timer_Threshold	15	s	0	3600	1
HV_SOC_Level_1_Min_Threshold	3770	Minimum State-Of-Charge percentage for operator Level 1 Warning	0	percent	0	100	1
HV_SOC_Level_2_Min_Threshold	3769	Minimum State-Of-Charge percentage for operator Level 2 Warning	0	percent	0	100	1
HV_SOC_Level_3_Min_Threshold	3768	Minimum State-Of-Charge percentage for operator Level 3 Warning	0	percent	0	100	1

### VCU Software Feature Codes (Programmed with SDS):

Note: VCU programming, with SDS, requires using the Nexiq USB link 2 or 3 and a special interface harness that has the standard round 9 Pin connector and a rectangular 10 pin connector. PN 08-801-01 Electric Vehicle “Y” Adaptor Cable



ID	Name	Values	Read	Write
90 UDS D01D 000	ePTO Programmed Speed Switch Input Selection	0: Hardwired 1: CAN	Available	Fleet
90 UDS D00E 000	ePTO Motor Speed Throttle Down Ramp Rate	0 - 7500 rpm/s (1 rpm/bit)	Available	Fleet
90 UDS D006 000	External Body Builder PTO Configuration	0: Disable 1: Enable	Available	Fleet
90 UDS D01A 000	Master Switch for Setting Source	0: Hardwired 1: CAN	Available	Fleet

90 UDS D013 000	ePTO Preset Motor Speed 2 (Resume/Accel)		Available	Fleet
90 UDS D011 000	ePTO Initial Preset Motor Speed Select	0: Off 1: Preset 1 2: Preset 2 3: Preset 3 4: Preset 4 5: Preset 5 6: Preset 6	Available	Fleet
90 UDS D007 000	Cruise Control Cancel Switch Feature Enable	0: Disable 1: Enable	Available	Fleet
90 UDS D021 000	Remote Accelerator Pedal Position Input Selection	0: Hardwired 1: CAN	Available	Fleet
90 UDS D00A 000	ePTO Maximum Motor Speed	0 - 8000 rpm (1rpm/bit)	Available	Fleet
90 UDS D009 000	ePTO Minimum Motor Speed	0 - 8000 rpm (1rpm/bit)	Available	Fleet
90 UDS D00D 000	ePTO Motor Speed Throttle Up Ramp Rate	0 - 1500 rpm/s (1 rpm/bit)	Available	Fleet
90 UDS D010 000	ePTO Remote Preset On/Off Switch Enable	0: Disable 1: Enable	Available	Fleet
90 UDS D005 000	ePTO In Cab Mode	0: Disabled 1: Stationary Preset 2: Stationary Variable 3: Mobile Variable	Available	Fleet
90 UDS D00F 000	ePTO Bump Up/Down Step	0 - 500 rpm (1 rpm/bit)	Available	Fleet
90 UDS D019 000	Remote Accelerator Enable Switch	0: Disable 1: Enable	Available	Fleet
90 UDS D017 000	ePTO Preset Motor Speed 6	0 - 8000 rpm (1 rpm/bit)	Available	Fleet
90 UDS D01B 000	Remote ePTO Set/Coast Switch Input Selection	0: Hardwired 1: CAN 2: Both	Available	Fleet
90 UDS D012 000	ePTO Preset Motor Speed 1 (Set/Coast)	0 - 8000 rpm (1 rpm/bit)	Available	Fleet
90 UDS D01C 000	Remote ePTO Resume/Accelerate Switch Input Selection	0: Hardwired 1: CAN 2: Both	Available	Fleet
90 UDS D008 000	ePTO Max Vehicle Speed	0 - 150 kph (1 kph/bit)	Available	Fleet
90 UDS D020 000	Remote Accelerator Switch Input Selection	0: Hardwired 1: CAN	Available	Fleet


90 UDS D015 000	ePTO Preset Motor Speed 4	0 - 8000 rpm (1 rpm/bit)	Available	Fleet
90 UDS D00B 000	ePTO Disables with Brake	0: Disable 1: Enable	Available	Fleet
90 UDS D00C 000	ePTO Disables with Parking Brake	0: Disable 1: Enable	Available	Fleet
90 UDS D01E 000	ePTO In-Cab Operator Interface On/Off	0: Disable 1: Enable	Available	Fleet
90 UDS D014 000	ePTO Preset Motor Speed 3	0 - 8000 rpm (1 rpm/bit)	Available	Fleet
90 UDS D016 000	ePTO Preset Motor Speed 5	0 - 8000 rpm (1 rpm/bit)	Available	Fleet
90 UDS D024 000	Motor Shaft Rotational Direction	0: Clockwise 1: Counterclockwise	Available	Fleet
90 UDS D01F 000	Remote ePTO Variable Speed Switch Input Selection	0: Hardwired 1: CAN	Available	Fleet
90 UDS D004 000	ePTO Speed Control Mode	0: Disabled 1: Remote Operation Only 2: In Cab Operation Only 3: Remote and In Cab Operation	Available	Fleet

### Configuring 3<sup>rd</sup> Party Controllers that connect to the data link:

Please contact an application engineer for assistance with adding one of these devices.

### How to Test This Feature (Standard Feature Operation):

**Caution** - Verify the shaft direction prior to pump installation to avoid pump damage.



### Motor Spin Direction is Programmable

1. To determine if the PTO is working, depress the PTO switch in the cab to the on position.
2. Ensure the indicator light in the top section of the PTO switch illuminates indicating PTO engagement.
3. Ensure the PTO indicator light in the gauge cluster illuminates when engaging the PTO. A flashing indicator on the PTO Switch would indicate a problem with the system.
4. Visually check to see if the PTO motor shaft is spinning in the desired direction.

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals.

## 25. ePower

**08PAB: HIGH VOLTAGE POWER ACCESSORY Connector Located Left Side Back of Cab, Provides Low Voltage and J1939 Signals to Enable High Voltage DC Body Builder Connection:**

NOTE – When this feature is ordered from the factory, the parameter programming required to enable it may have been turned off to prevent any DTCs from setting, at the plant. The parameter will need to be turned on, using the SDS programming software, to allow the system to work as desired. This parameter requires someone with Engineering permissions to change the parameter.

NOTE – Once the TEM ePower system has been installed and connected, create a case file for Vehicle Programming Group. Case File should state:  
TEM equipment has been installed on VIN# XXXXXXXXX. Please re-enable 08PAB at no charge.

Feature 08PAB provides a high voltage connection at the HVDM to provide power to be used with compatible Body Builder components.

**Feature Applicability to Vehicle Platforms:**

- Electric Vehicle (eMV)

**Note: ZE Onboarding training will cover all eMV safety content. This training is needed prior to ePower integration activities. Onboarding training covers all safety content including isolation procedures and commissioning/de-commissioning.**

**Extended Description:**


**WARNING** – To avoid serious personal injury, possible death, or damage to the vehicle, when servicing the HVDM connection, Level 2 isolation is required. Ensure that only trained personnel using the appropriate procedures and safety equipment are working on these connections. Course information can be found at the [International Motors - Learning](#) website.

**NOTE** – Connecting to the ePower system can be complex as each bodybuilder’s requirements may be different-. It is recommended that you contact an application engineer so the engineer can gather your requirements and provide details on how to best integrate the ePower system.

A switch, labeled PTO, in the cab is used to turn on the system.



### System Block Diagrams:



### Body Controller Software Feature Codes:

- 0597788 BCM PROG, ePower Cluster Display

### Body Controller Software Feature Code Parameters:

Parameter	ID	Description	Default	Units	Min	Max	Step
PTO_Engagement_Status_Signal_Delay	3633	Parameter for the debounce of the PTO Engagement status message from TCM	10	ms	100	500	1
PTO_Veh_Spd_Threshold	3659	This Parameter sets the vehicle speed at which the PTO will not be engaged if the threshold is exceeded	3	mph	3	100	1

## 25.4. ePower LV Hardware Interface Integration

### 25.4.1. LV Voltage Range

Customer supplied system shall operate from the following operating voltage range.

	Unit	Min	Nom	Max
<b>LV supply: input current</b>	A	tbd	tbd	tbd
<b>LV supply: input voltage</b>	V	9	12	18

Table 1: LV voltage range

## 25.5. ePower Electrical Interface Integration

### 25.5.1. LV Connector

A 10 pin interface connector provides low voltage, J1939 signals and an enable circuit to enable the High Voltage DC .

A dedicated 10-pin connector is supplied for the customer LV connections.

The connector is taped to the main bundle of the VCU harness, BOC on Left Rail, in the same manner that 0008HAB is taped to the main bundle of the chassis harness.

The 10 pin connection is capped. Store the cap in a safe place after removing for future use.

120 Ohm terminating resistor is required for the data link pins.

10-pin connector for the LV connection has the following pinout:



ePower Low Voltage Connector and Pin Outs

Pin Ref.	Signal	Level	Description
1	N.C.		Not used in the current design, reserved for the future use.
2	N.C.		Not used in the current design, reserved for the future use.
3	N.C.		Not used in the current design, reserved for the future use.
4	N.C.		Not used in the current design, reserved for the future use.
5	12V	0-12V	Low voltage battery connection, 12V positive.
6	CAN High ePower	0-5V	This is a 500K line and that this is ONLY for the HV Handshake.
7	CAN Low ePower	0-5V	This is a 500K line and that this is ONLY for the HV Handshake.
8	ePower Enable	0-12V	Used to enable the customer supplied system.
9	N.C.		
10	GND	0-12V	Low voltage battery connection, ground.

Table 2: LV connector pinout

#### Parts Associated with This Feature:

PART NUMBER	DESCRIPTION
<b>ePOWER LOW VOLTAGE HARNESS CONNECTOR 6099</b>	
4194078C1	10 WAY CONNECTOR
3830792C1	TERMINAL FOR PINS 5 & 10
3532128C1	SEAL FOR PINS 5 & 10
4086472C1	TERMINAL FOR PINS 6,7, & 8
3573653C1	SEAL FOR PINS 6,7, & 8
<b>ePOWER LOW VOLTAGE MATING CONNECTOR 6099A</b>	
6737277C1	10 WAY CONNECTOR
3830792C1	TERMINAL FOR PINS 5 & 10
3532128C1	SEAL FOR PINS 5 & 10
4086472C1	TERMINAL FOR PINS 6,7, & 8
3573653C1	SEAL FOR PINS 6,7, & 8
3766715C1	BACK-SHELL

#### 25.5.2. LV Fuse for VBATT Connection

Vehicle has internal 15A fuse that protects 12V loading of the bus. Upfitter is responsible to determine if additional fuse protection is necessary.

### 25.5.3. LV Fusing

Customer supplied system shall have internal LV fuses to protect various internal loads.

### 25.5.4. ePower Enable

The Enable pin is rated for 12V output, 100mA and it is used to enable the customer supplied system.

### 25.5.5. CAN System Diagram

The customer supplied system shall be connected to the ePower per the following CAN network diagram.

Ensure the proper terminating resistor standards are followed.

### 25.5.6. High Voltage Range

Customer supplied system shall operate from the following operating voltage range.

	Unit	Min	Nom	Max
<b>HV supply: input current</b>	A		20	20
<b>HV supply: input voltage</b>	V	473	608	690

HV Voltage Range Table

### 25.5.7. HVDM Connection

**WARNING** – To avoid serious personal injury, possible death, or damage to the vehicle, when servicing the HVDM connection, Level 2 isolation is required. Ensure that only trained personnel using the appropriate procedures and safety equipment are working on these connections. Course information can be found at the [International Motors - Learning](#) website.

Customer supplied system shall be connected to the HVDM. The HVDM has two 20kW outputs that are labeled as AC-R/Aux2 and AC-F/Aux1, as shown below. If only utilizing 1 output, the customer supplied system should be connected to AC-F/ Aux1.



HVDM Connection Interface

### **25.5.8. HV Connector Plugs**

HVDM headers AC-F and AC-R (as per above image) are protected by plugs. These plugs complete the HVIL circuit. They should only be removed if Customer supplied system is connecting to that outlet. If only using 1 outlet, the AC-R/Aux2 plug must remain installed. Plugs should be retained after installation (recommend glovebox).

### **25.5.9. HV Connector**

HVAC-R (HVDM Header: TE P/N 2103124-1 Key-A)

HVAC-F (HVDM Header: TE P/N 2103124-2 Key-B)

### **25.5.10. Mating Keyed Connectors F (Plug/Mating connector for HV Harness)**

*Option-1: HV plug Connector with Pass Through HVIL W/Multicore cable.*

TE reference Drawing Number: C-2103436

TE Application Specification: 114-13310

Option-2: HV plug connector with Shunted HVIL W/Multicore cable.

TE reference Drawing Number: C-2103437

TE Application Specification: 114-13305

Option-3: HV Plug connector with Shunted HVIL W/Single or individual cable

TE reference Drawing Number: C-2103176 and C-2103177

TE Application Specification: 114-13259


### 25.5.11. HV Cable

Customer supplied system shall be connected using HV Cable harnesses. These Harnesses must have:

- (i) All high voltage cables and covers are required to be orange in color for safety recognition.
- (ii) The proper labeling with Customer Part number and description of the part number.
- (iii) Cables must be routed properly with their bending diameter requirement (as per wire supplier (like Leoni, H&S)).
- (iv) These HV wires must be protected by the proper sleeves.
- (v) These Harnesses must be clipped/attached properly to secure the position of the harnesses.
- (vi) Must use the strain relief back of the HV connector (as per Connectors supplier requirements). To avoid any damage in the harness.
- (vii) These Wire Harnesses must build with the proper wires as per TE mating connectors (plugs) assembly requirements.

The wire selection based on the plugs as defined in section 25.5.8.

#### **For Option-1**




#### ***Cable Option***

Cable supplier: KROMBERG & SCHUBERT  
Cable Construction: 2X 4.0 mm<sup>2</sup> and 2X 0.5 mm<sup>2</sup>  
Supplier cable part number: 64994093

KROMBERG & SCHUBERT is a trademark.

## For Option-2



<p><b>Cable Option</b></p> <p>Cable Supplier: COROPLAST Cable Construction: 2 x 4.0 mm<sup>2</sup> Supplier Cable Part Number: 9-2641</p>	<p><b>Recommended Subcomponents:</b></p> <p>1-968853-3 MCP Receptacle Contact, 2.8 mm 2103157-1 or 1-2103157-1 Shield Plug 1587723-3 Inner Ferrule 1587724-3 Outer Ferrule 2103153-1 Spacer 2103154-1 Cable Seal 2103013-1 Cable Seal Retainer 2103155-1 Collet</p>	<p><b>Cable Option</b></p> <p>Cable Supplier: DARKA Cable Construction: 2 x 4.0 mm<sup>2</sup> Supplier Cable Part Number: FLR91XBC33X</p>	<p><b>Recommended Subcomponents:</b></p> <p>1-968853-3 MCP Receptacle Contact, 2.8 mm 1-2103157-2 Shield Plug 1587723-2 Inner Ferrule 1587724-2 Outer Ferrule 2103153-1 Spacer 2103154-3 Cable Seal 2103013-2 Cable Seal Retainer 2103155-3 Collet</p>
<p><b>Cable Option</b></p> <p>Cable Supplier: Huber+Suhrner Cable Construction: 2 x 4.0 mm<sup>2</sup> Supplier Cable Part Number: 12 582 308</p>	<p><b>Recommended Subcomponents:</b></p> <p>1-968853-3 MCP Receptacle Contact, 2.8 mm 1-2103157-2 Shield Plug 1587723-2 Inner Ferrule 1587724-2 Outer Ferrule 2103153-1 Spacer 2103154-2 Cable Seal 2103013-2 Cable Seal Retainer 2103155-2 Collet</p>		

## For Option-3

CABLE	RECOMMENDED CABLE-SPECIFIC TERMINATION COMPONENTS	
	PART NUMBER	DESCRIPTION
Supplier: HUBER+SUHNER Construction: 4 mm <sup>2</sup> Part Numbers: 12582674 (Orange) 85002132 (Orange/Black)	1-968853-3	MCP 2.8-mm Receptacle Terminal
	1587828-3	Inner Ferrule
	1587829-3	Outer Ferrule
	1587826-3	Cable Seal
	1587827-3	Cable Seal Retainer
Supplier: LEONI Construction: 4 mm <sup>2</sup> Part Number: 76231175A (Orange)	1-968853-3	MCP 2.8-mm Receptacle Terminal
	1587828-3	Inner Ferrule
	1587829-3	Outer Ferrule
	1587826-3	Cable Seal
	1587827-3	Cable Seal Retainer
Supplier: Judd Wire Inc. Construction: 3 mm <sup>2</sup> Part Number: C09494 (Orange)	1-968853-3	MCP 2.8-mm Receptacle Terminal
	1587828-2	Inner Ferrule
	1587829-2	Outer Ferrule
	1587826-2	Cable Seal
	1587827-2	Cable Seal Retainer

### 25.5.12. HVDM Fuse

The HVDM has internal fuses.

- (i) 30A fuse to protect AC-F output, and
- (ii) a separate 30A fuse to protect the AC-R output.
- (iii)


Note: Control logic will limit the current available, depending on the SOC. The max output will be closer to 22A.

This is a non-serviceable fuse and cannot be serviced in the field. Fuse failure will require contacting Tech Service so a case file can be opened. HVDM replacement instructions will be provided.

Note: Customer connected loads must be within this range to protect these main fuses in HVDM. In case of wire size reduction in customer load harnesses, Customer must use their own distribution box with fuses to protect HV wiring.

### 25.5.13. HVDM Location

HVDM location within eMV is shown in a figure below.



HVDM location

### 25.5.14. HV Fuse

Customer supplied system shall have an internal fuse to protect their own high voltage components.

### **25.5.15. HVIL**

Customer supplied system shall internally monitor HVIL status and report status via CAN network.

HVIL stands for High-Voltage Interlock Loop. It is a crucial safety feature in hybrid and electric vehicles designed to protect people during the assembly, repair, maintenance, and operation of these vehicles. The HVIL system monitors high-voltage components and ensures that if any high-voltage connection becomes loose, disconnected, or damaged, the system will alert the driver and prevent potential hazards.

**Warning** For servicing the HVDM connection, Level 2 isolation is required. Ensure that only trained personnel using the appropriate procedures and safety equipment are working on these connections.

## **25.1 System Active Discharge**

Customer supplied system is expected to stay connected to HVDM during the active discharge. Vehicle is responsible to actively discharge all HV components during the vehicle shut down sequence to the voltage below 60V within 5 seconds.

If the components are disconnected from the HVDM via the internal contactor, the system is then responsible to actively discharge the component within 5 seconds of the disconnection.

## **25.2 Internal Contactor**

If the customer supplied system has internal contactor, they should stay connected to HVDM during the shutdown and the active discharge process. In this case vehicle will actively discharge the high voltage capacitors within vehicle and high voltage capacitors within the customer supplied system.

In case that the customer supplied system opens internal contactors before the vehicle active discharge sequence they are responsible for discharging the internal high voltage capacitors to below 60V within 5 seconds.

During this process, the customer supplied system shall broadcast internal high voltage values to confirm that they have discharged their system.

## **25.3 System After-Run Operation**

The ePower system will remain operational, if the PTO switch is on, when vehicle is keyed off. The ePower system shall continue to operate as long as battery SOC remains above the predetermined threshold and software/hardware interlocks are met.

**How to Test This Feature:**

1. Contact your Application Engineer for test procedure

**References:**

Refer to the applicable International® Circuit Diagrams and Service Manuals

**26. General Electrical Section:**

**Description:** - International vehicle electrical systems are becoming increasingly complex with the addition of a BCM, electronically driven instrument gauges, and Antilock Brake Systems (ABS) to name a few. While most systems still operate on battery voltage (12 volts), some systems operate at as high as 700 volts (battery powered vehicles) and as low as five (5) volts (pressure sensors).

International publishes Electrical Circuit Diagrams and Service Manuals for all its models. Body builders and installers should refer to these manuals before connecting body lights and accessories to the vehicle electrical system to assure that circuits chosen are both appropriate and not overloaded. Modifications not defined in the circuit diagram book are not to be made to the vehicle electrical/electronic control systems without first contacting International's Technical Service Department at 1-800-336-4500.

**26.1. "Red Gel Coat" Removal From Electrical Connections**

The following will provide information on how to properly soften and remove the 'red gel coat' from, ground studs and any other electrical connections that are covered with this protective coating. This will greatly ease the disassembly of these connections, preventing stud/nut damage caused by using too much force to overcome the gel coat.

**SPECIAL TOOL(s) / SOFTWARE**

<b>Tool Description</b>	<b>Tool Number</b>	<b>Comments</b>	<b>Instructions</b>
Standard Wire Brush	N/A	Source Locally	
Small Scraper	N/A	Source Locally	
Small Paint Brush	N/A	Source Locally	
Small, metal cup/bowl/container	N/A	Source Locally	

## **SERVICE PARTS INFORMATION**

**NOTE** – After the container has been opened, it should be used within 6 months. Potency will decrease after 6 months.

<b>Description</b>	<b>Part Number</b>	<b>Quantity Required</b>	<b>Notes</b>
Blue Bear 600GL Coating Softener/Remover	BBISG1GEANDT1 or BBISGQTEANDT1	1 (1 Quart)	Tools Catalog
Mineral Spirits	N/A	1 container	Source Locally
Grafo Dielectric Grease or Tribo Tuff Blue Dielectric	Grafo - 472141C2 Tribo Tuff - 2519646C1	1 container	Parts Catalog



## **REPAIR STEP(s)**

**Warning** - To prevent property damage, personal injury and/or death, park vehicle on a hard, flat surface, turn the engine off, set the parking brake, and install wheel chocks to prevent the vehicle from moving in either direction.

**Warning** – To prevent property damage, personal injury and/or death, if the vehicle must be raised, do not work under the vehicle supported only by jacks. Jacks can slip or fall over.

**Warning** – To prevent personal injury and/or death, always wear safe eye protection when performing vehicle maintenance.

**Warning** – To prevent property damage, personal injury and/or death, keep flames or sparks away from vehicle and do not smoke while servicing the vehicle's batteries. Batteries expel explosive gases,

**Warning** - To prevent property damage, personal injury, and / or death, remove the ground cable from the negative terminal of the battery box before disconnecting any electrical components. Always connect the ground cable last.

**Caution** - Wear chemical-resistant gloves and safety glasses while applying. Respiratory masks may be considered to avoid inhaling any vapors. Avoid contact with painted surfaces or any surface not coated with the Red gel. See [MSDS sheet](#) for more safety info.

### **REMOVAL PROCEDURE:**

1. Install Wheel Chocks
2. Obtain Service Information for proper procedure on batt. disconnect, starter and/or ground stud(s) removal.
3. Obtain Service Part(s)
4. Obtain Service Tool(s)

**Important** – Refer to the warnings and directions provided with the product.

5. Shake the Gel Softener container well to homogenize the contents and open the container slowly

6. Pour the required amount of chemical into a small metal container. Using a paint brush, apply liberally on to red coated threads, nuts and studs (metal surfaces). See **Figure #1**. Avoid dripping onto other surfaces. DO NOT apply to rubber, wire insulation etc. Only use this on metallic surfaces.

7. Let sit for 10-15 minutes to allow chemical to soften the Red coating.

**Note:** A longer set time will yield better results.

8. Use a scraper, wire brush and rag to remove as much coating as possible. See **Figure #2**. A second application of the softener chemical may be required - use discretion prior to loosening nuts/studs.

9. To remove remaining finish or residues, use abrasive pad or cloth dipped in odorless mineral spirits.


### **REASSEMBLY PROCEDURE:**

1. Remove any excess Red Gel Coat on mating surfaces of eyelet connectors, nuts, washers, threads or any contact surface that may disrupt continuity, BEFORE reassembly.


2. After referencing the manual and repairs are complete, reconnect batteries per the standard procedure called out in the manual and apply 'Grafo' or 'Tribo Tuff Blue' dielectric grease to any of the connections removed, that originally contained the red coating.

3. Work areas and tools can be cleaned w/ mild degreaser and/or detergent/soap and water. Wash hands with cold water and soap.

4. Disposal: Any unused Gel Softener remaining in the small metal container, should be placed outdoors to evaporate and dry. Once dry, the container can be cleaned with degreaser or mineral spirits.



**Figure #1: Applying Softener Gel to Dash Panel Ground Studs**



**Figure #2: Dash Panel Ground Studs - Before and After**

## 26.2. Connecting to 12 Volt Circuits

Connecting to 12-volt circuits can be a straightforward process if you follow some key steps. Here is a general guide to help you get started:

1. **Identify the Power Source:**

Using the circuit diagrams, locate a desired battery fed, ignition fed or accessory fed 12-volt power source.

Also ensure the power source can manage the additional load of the new circuit. Ensure that any added circuits will not induce parasitic loads that will unintentionally drain the batteries.

2. **Choose the Right Wiring:**

Use appropriate gauge wire for the current draw of your devices.

3. **Install a Fuse:**

Always install the fuse close to the power source to protect the circuit. The fuse rating should be slightly higher than the maximum current draw of your devices.

4. **Run the Wires:**

Route the wires from the power source to the location of your accessory. Use wire loom or conduit to protect the wires from abrasion and heat.

5. **Ground the Circuit:**

Connect the negative wire to a good chassis ground. Clean the grounding point to ensure a solid connection.

6. **Test the Circuit:**

Before finalizing the installation, test the circuit to ensure everything is working correctly. Use a multimeter to check for proper voltage and continuity.

## 26.3. Recommended Circuit Protection

Adding fuses to 12-volt circuits is crucial for protecting your electrical system from overcurrent that can cause damage. Here are some standard practices to follow:

1. **Determine the Correct Fuse Size:**

Calculate the maximum current draw of your circuit by adding up the current ratings of all devices connected to it. Use a fuse rated at approximately 125% of the normal operating current to allow for safe operation without unnecessary blowing of the fuse.

2. **Fuse Placement:**

Place fuses as close to the power source as possible to protect the entire length of the circuit.

Each individual circuit should have its own fuse to provide targeted protection and simplify fault troubleshooting.

**3. Types of Fuses:**

Use the appropriate type of fuse for your application. Common types include blade fuses, glass tube fuses, ceramic fuses and circuit breakers.

For high-current applications like starter motors, consider using fusible links or circuit breakers instead of standard fuses.

**4. Installation Tips:**

Ensure the fuse is compatible with the fuse holder and that connections are secure.

Regularly inspect fuses for signs of damage or corrosion and replace them with the exact type and rating if they blow.

**5. Safety Considerations:**

Always disconnect the battery or power source before working on the circuit.

Avoid using a fuse with a higher rating than recommended, as this can prevent the fuse from blowing during an overcurrent situation, potentially causing damage.

**Circuit Protection by Wire Gauge:**

WIRE GAUGE	PROTECTIVE DEVICE SIZE	MAXIMUM CURRENT (AMPS)
18-GUAGE	10 AMP FUSE/ CIRCUIT BREAKER	8 A
16-GUAGE	15 AMP FUSE/ CIRCUIT BREAKER	12 A
14-GUAGE	20 AMP FUSE/ CIRCUIT BREAKER	16 A
12-GUAGE	25 AMP FUSE/ CIRCUIT BREAKER	20 A
10-GUAGE	30 AMP FUSE/ CIRCUIT BREAKER	24 A
8-GUAGE	12 GAUGE FUSIBLE LINK	80 A
6-GUAGE	10 GAUGE FUSIBLE LINK	108 A
4-GUAGE	2-12 GAUGE FUSIBLE LINK	160 A
<b>CAUTION – Wire gauge is designed to match fuse / circuit breaker ratings. Do not increase the size of a circuit breaker or fuse. This might cause wiring to overheat.</b>		

**Circuit Protection by wire Gauge Table**

**Circuit Protection Devices - Fuses and Circuit Breakers:**

PART NUMBER	DESCRIPTION	SIZE	COLOR
<b>CIRCUIT BREAKERS</b>			
3536177C1	TYPE III — MANUAL RESET	7.5 A	BROWN
3536178C1	TYPE III — MANUAL RESET	10 A	RED
3536179C1	TYPE III — MANUAL RESET	15 A	BLUE
3536180C1	TYPE III — MANUAL RESET	20 A	YELLOW
3536181C1	TYPE III — MANUAL RESET	25 A	WHITE
3536182C1	TYPE III — MANUAL RESET	30 A	GREEN
3529688C1	TYPE III - MINI	20 A	YELLOW
3529690C1	TYPE III - MINI	30 A	GREEN
<b>THERMAL FUSES</b>			
3534208C1	MINI — SAE J2077	5 A	TAN

3546109C1	MINI — SAE J2077	7.5 A	BROWN
3534209C1	MINI — SAE J2077	10 A	RED
3534210C1	MINI — SAE J2077	15 A	BLUE
3534211C1	MINI — SAE J2077	20 A	YELLOW
3534212C1	MINI — SAE J2077	25 A	NATURAL
3534213C1	MINI — SAE J2077	30 A	GREEN
131224C1	AUTOFUSE	20 A	YELLOW
571691C1	AUTOFUSE	30 A	GREEN
<b>INLINE SOCKET AND CABLE FOR CIRCUIT BREAKER/FUSE</b>			
1676841C91	INLINE SOCKET WITH CABLE	20 A	BLACK
1682115C91	INLINE SOCKET WITH CABLE	30 A	BLACK

**Fuse and Circuit Breaker Protection Device Table**

**Circuit Protection Devices - Fuses and Circuit Breakers:**

PART NUMBER	DESCRIPTION	SIZE	COLOR
<b>CIRCUIT BREAKERS</b>			
3536177C1	TYPE III — MANUAL RESET	7.5 A	BROWN
3536178C1	TYPE III — MANUAL RESET	10 A	RED
3536179C1	TYPE III — MANUAL RESET	15 A	BLUE
3536180C1	TYPE III — MANUAL RESET	20 A	YELLOW
3536181C1	TYPE III — MANUAL RESET	25 A	WHITE
3536182C1	TYPE III — MANUAL RESET	30 A	GREEN
3529688C1	TYPE III - MINI	20 A	YELLOW
3529690C1	TYPE III - MINI	30 A	GREEN
<b>THERMAL FUSES</b>			
3534208C1	MINI — SAE J2077	5 A	TAN
3546109C1	MINI — SAE J2077	7.5 A	BROWN
3534209C1	MINI — SAE J2077	10 A	RED
3534210C1	MINI — SAE J2077	15 A	BLUE
3534211C1	MINI — SAE J2077	20 A	YELLOW
3534212C1	MINI — SAE J2077	25 A	NATURAL
3534213C1	MINI — SAE J2077	30 A	GREEN
131224C1	AUTOFUSE	20 A	YELLOW
571691C1	AUTOFUSE	30 A	GREEN
<b>INLINE SOCKET AND CABLE FOR CIRCUIT BREAKER/FUSE</b>			
1676841C91	INLINE SOCKET WITH CABLE	20 A	BLACK
1682115C91	INLINE SOCKET WITH CABLE	30 A	BLACK

**Fuse and Circuit Breaker Protection Device Table**

## 26.4. Color Code System for International® Truck Wiring:

### Wiring Color Code System:

COLOR	DESCRIPTION
RED	BATTERY FEEDS
PINK	IGNITION FEEDS
LIGHT BLUE	ACCESSORY FEEDS
YELLOW	HEADLIGHT SYSTEM (DAYTIME RUNNING LIGHTS, FOG, HI-BEAM, ETC.); DATA LINK J1939 (+)
DARK BLUE	INTERIOR LIGHTS (DOME, PANEL, ETC.); DATA LINK J1708 (+)
BROWN	EXTERIOR LIGHTS (TAIL, MARKER, CLEARANCE, ETC.)
ORANGE	EXTERIOR LIGHTS (TURN, BACK-UP, ETC.)
GRAY	CHASSIS SYSTEMS (HORN, ETC.);
TAN	CHASSIS MONITORING SYSTEMS (GAUGES)
GREEN	DATA LINK J1939 (-)
LIGHT GREEN	DRIVER AID SYSTEMS (WINDSHIELD WASHER, HEATER, ETC.)
VIOLET	CONTROLS - ELECTRONIC
WHITE	GND
BLACK	BATTERY GND CABLES OR COMPUTER DATA LINK SYSTEMS

**NOTE** - The wiring in multiple conductor jacketed cable does not follow the above color code system. see the electrical circuit diagram manual for specific colors and circuit numbers used with each system. use only "GXL", "SXL" or "TXL" insulated wire. crimp and solder all connections.

**Wiring Color Code Table**

## 26.5. Electrical Components Commonly Used by Equipment Installers:

### Components Table:

PART NUMBER	DESCRIPTION
<b>AT FUSE BLOCK</b>	
3536294C1	TERMINAL, FUSE BLOCK (18/20 GAUGE)
3573312C1	TERMINAL, FUSE BLOCK (14/16 GAUGE)
3573311C1	TERMINAL, FUSE BLOCK (10/12 GAUGE)
<b>AT TAIL LIGHTS</b>	
589390C1	SEAL, WIRE - (BLUE) .165-.138 O.D. CABLE (12-14 GAUGE)
589391C1	SEAL, WIRE - (GRAY) .137-.111 O.D. CABLE (14-16 GAUGE)
1652325C1	SEAL, WIRE - (LT GN) .110-.080 O.D. CABLE (16-20 GAUGE)
1661375C2	BODY CONNECTOR, 5-WAY MALE
1661377C1	TERMINAL, FEMALE - 14/16 GAUGE
1661376C1	LOCK, 5-WAY MALE CONNECTOR

1677851C1	BODY CONNECTOR, 5-WAY FEMALE
1671609C1	TERMINAL, MALE - 14/16 GAUGE
1677914C1	LOCK, 5-WAY FEMALE CONNECTOR
587579C1	SEALING PLUG (FOR EMPTY CONNECTOR CAVITIES)
<b>NOTE</b> – Any unused circuit cavities must be plugged with the sealing plugs provided with the chassis harness.	

### **Commonly Used Electrical Integration Small Components Table**

#### **26.6. Suppression**

International® strongly recommends electromagnetic devices be electrically suppressed, when adding devices such as relays, magnetic switches, and solenoids.

Unsuppressed electromagnetic devices can generate large voltage spikes which are conducted into the vehicle electrical system. These voltage spikes may adversely affect customer added electronic devices and in some instances may affect International installed electronic components.

When installing electromagnetic devices, specify suppressed units. If suppressed units are not available, diode suppression may be added as shown below:

The following suppressed relays and magnetic switches are available from International.

#### **Suppressed Relays and Magnetic Switches:**

PART NUMBER	DESCRIPTION
1691520C91	MAGNETIC SWITCH - CONTINUOUS DUTY (SUPPRESSED) 100 AMP
1693479C91	MAGNETIC SWITCH - INTERMITTENT DUTY (SUPPRESSED) 100 AMP
3519350C1	MICRO RELAY – SPDT (SUPPRESSED), NO – 20 AMP, NC – 10 AMP

#### **26.7. Welding Information**

Electric Welding on the electric vehicle is not recommend. The exception is welding performed at the rear end of the frame to accommodate lift gate installations.

Whenever electric welding is done on any part of the vehicle, it is not necessary to disconnect the International electronic modules in the cab such as the BCM, RPM, and the instrument cluster. The welder's GND must be connected as close to the weld as possible. Disconnect both the positive (+) and the negative (-) battery cables including the electronic power feeds prior to electric welding. If it is necessary to weld close to an electronic component, it is recommended that the component be temporarily removed.

Devices should also be covered with a protective blanket to prevent splatter from damaging any components.

Consult manufacturer's instructions for all other electronic modules such as Bendix ABS and WABCO ABS.

## 26.8. Routing Guidelines

Any hosing, tubing, battery cable, wiring or electrical harness must not rub on a sharp edge. However, due to the high abrasion resistance of synflex tubing, it is permissible for synflex tubing to make contact with the lower edge of the frame rail flange when the tubing is making the transition from the outside to down and under the rail. This does not mean that proper clearance or the need for protective wrap is not needed when synflex line contacts sharp edges or threaded fasteners.

Any hosing, tubing, battery cable, wiring or electrical harness must not rub or make contact with a hot surface.

Nothing should rub or make contact with the copper compressor discharge tubing other than the clamp(s) that support it.

All hosing, tubing, battery cables or electrical harnesses should be supported at least every 18" to 20".

Strap locks used to directly clamp, or support battery cables or main engine wiring harnesses must be no less than 7/16" in width.

Strap locks are not to be used on any bulk hose materials (heater hoses, make-up lines, etc.).

Strap locks are not to be used on any Orange high voltage circuits or conduit.

### Route and Clip Recommendations:

#### Electrical Harness:

PROBLEM	REQUIREMENT
SHARP OR ABRADING SURFACE	NO CONTACT
TENSION ALONG HARNESS/WIRES/HOSE	NONE
DISTANCE FROM MOVING PARTS	1"
CONNECTOR CLIPPED TO AVOID DAMAGE	YES
CONNECTORS ARE SEALED	YES
MAX EYELETS PER STUD	3
HARNESS PROTECTED FROM DAMAGE	YES
DRIP POINT FOR HARNESS	YES
DISTANCE OF HARNESS TO FLAMMIBLE FLUIDS	1/2"
HARNESS LOCATION TO FLAMMIBLE FLUIDS	NOT DIRECTLY UNDER
BATTERY CABLES TO FLAMMIBLE FLUIDS	1" MINIMUM

BATTERY CABLE TO CONDUCTIVE SURFACE	1/2" MINIMUM
BATTERY CABLE TIE STRAP	1/2" (250 POUND) WIDE
HARNESS CONTACT WITH METAL SURFACE	NO RELATIVE MOTION
P-CLAMPS – ELECTRICAL	CUSHIONED ONLY
P-CLAMPS FASTENING SUPPORT	NO CANTILEVER
HIGH PRESSURE PIPE/HOSE (>200 PSI)	DON'T CLIP ANYTHING TO THEM
HARNESS THROUGH METAL HOLES	USE GROMMET
FULL ARTICULATED POSITION	OPERATES WITH OUT DAMAGE
CLIPPING FIXED MAX DISTANCE - HARNESS	14"
SPLICES	USE SHRINK WRAP


## 26.9. Wire Splicing and Termination - Standard Terminals and Splices:

### Standard Terminals

1. Cut the cable just before the insulation wings on the terminal.
2. Remove the insulation being careful not to cut any of the wire strands.
3. Position cable in the new terminal.
4. Hand crimp the core wings first, then the insulation wings.

**NOTE** - Always use the recommended crimp tool for each terminal. A detailed crimp chart is included in the repair kit.

5. Solder all hand crimped terminals and electrically check for continuity.




### Standard Terminal

#### 1. MATING END

2. CORE WINGS
3. INSULATION WINGS
4. CABLE
5. LOCK TANG
6. INSULATION
7. WIRE STRANDS
8. SOLDER

**Splice Inspection:**



**Splice Inspection**


- A. TERMINAL APPLICATION
  1. INSULATION CRIMP
  2. WIRE STRANDS VISIBLE IN THIS AREA
  3. CORE CRIMP
- B. SOLDER APPLICATION
  4. GOOD SOLDER APPLICATION
- C. CRIMP AND SEAL HEAT APPLICATION
  5. EVIDENCE OF GLUE

**Splice Clip Installation**

**NOTE** - A new clip must be located a minimum of 1.5 inches (40 mm) from a connector, sleeve or another clip.

1. Cut off the old clip or bad section of wire.
2. Remove the insulation being careful not to cut any of the wire strands.
3. Install the proper clip on the wire strands.
4. Hand crimp the clip until securely fastened.
5. Solder the clip and electrically check for continuity.

6. Cover the entire splice with splice tape. Extend the tape onto the insulation on both sides of the splice(s).



**Splice Clip Installation**

1. INSULATION
2. WIRE STRANDS
3. CLIP (POSITIONED CORRECTLY)
4. CRIMPED CORRECTLY
5. SOLDER
6. TAPE

**Crimp and Seal Splice Sleeve Installation:**

**Parts Information:**

Part Number	Description	Quantity
3517501C1	12-10 AWG Splice	2
3517502C1	16-14 AWG Splice	7
3517503C1	22-18 AWG Splice	2
2644000R1	Dual Wall Heat Shrink, 50mm	50

**NOTE** - A new sleeve must be located a minimum of 1.5 inches (40 mm) from a connector, clip or another sleeve.


1. Cut off the old sleeve or bad section of the wire.
2. Remove insulation being careful not to cut any of the wire strands.
3. Install the proper sleeve on the wire strands, making sure the ends of the wire hit the stop.

4. Hand crimp to the sleeve. Gently tug on the wire to make sure that they are secure.

**NOTE** - Always use the recommended crimp tool for each sleeve. A detailed crimp chart is included in the Repair Kit.

**Caution** - Use an appropriate heat gun. Do not use a match or open flame to heat the sleeve seal.

5. Electrically check the sleeve and wire cable for continuity.



### Crimp and Seal Splice Sleeve Installation

1. WIRE STRANDS
2. WIRE STOP
3. CRIMP CONNECTOR
4. EVIDENCE OF GLUE


#### Data Link Repair:

##### J1939/11 Shielded Only

Repairs to damaged J1939 circuits should be accomplished using identical types of wiring. Splices should be crimped, soldered and covered with heat shrink. Ensure the twist in the wire pair is maintained and that any wire bundles in the engine compartment are shielded and covered with heat shrink.

#### Wire Repair

This instruction addresses termination and splicing of J1939 wire.




**Preparation of J1939 Wire for Connection**

1. Strip back (view C) outer shield 3 1/8 in. (76 mm).
2. Strip (view A) green wire and yellow wire 1/4 in. (6.35 mm) being careful not to cut individual strands.
3. Re-twist all three wires if they have separated.
4. Sleeve drain wire (view B) may be soldered to aid in sleeving.
5. Install terminals on green and yellow wire ends, and crimp.
6. The 1/4" heat shrink tube (view D) will be shrunk later after the wires have been inserted into the crimp connector.


### **Wire Splicing**

1. Strip wire ends 1/4 inch.
2. Re-twist any loose wires.




**Re-Twist Any Loose Wires**

3. Slide 2-inch pieces of heat shrink tube over wire for later use.




**Put Heat Shrink Tube Over Each Wire**

4. Put heat shrink tube over each wire.
5. Insert ends of wires into splice joint and crimp.
6. Solder the wires and crimp joint together.




**Solder Wires Together**

7. Center heat shrink tube over splice and shrink.




**Center Heat Shrink Tube Over Splice**

8. Wrap wires with foil tape. Maintain at least 1/2 wrap overlap.



**Center Heat Shrink Tube Over Cable**

9. Center heat shrink tube over the splice and shrink.



**Center Heat Shrink Tube Over Cable**

**J1939 HIGH SPEED DATA LINK CABLE (SAE J1939/15):**

The information in this section applies to all severe and medium vocational series models.

Performing the proper repairs or modifications of the cable is critical to the integrity and performance of the vehicle systems. (For repair procedure see Electrical Troubleshooting Guide - S08250 or Data Link Repair in this manual.) This information based on SAE J1939/15 and TMC RP 142.

These instructions are intended for modifications that meet the SAE spec, i.e., no internal resistor. When extending the backbone, the proper materials must be used. The data link cable consists of a twisted pair of insulated wires and are covered by an insulating jacket. The data link cable must meet the SAE - specified characteristic impedance of 120-ohms. Never splice regular automotive type wire such as GXL, SXL,

TXL into the data link cable. Use data link cable furnished by Raychem, part number 2021D0309.

The backbone is the main part of the cable. This is terminated at each end with a 120-ohm resistor. When adding a device, the backbone must be extended. This is done by removing the resistor, inserting the backbone extension, then plugging the resistor and the device into the extension.

**J1939:**

J1939 is a high-speed serial communications data link. The system requires two terminating resistors. The wire between these two resistors is called the backbone. The backbone cannot be longer than 131.2 feet (40m). A module can tap into the backbone. This point is called the Node. The distance between two nodes cannot be less than 3.9 inches (0.1m). The cable length from the node to the module cannot be longer than 9.8 feet (3m).

**26.10. HIGH VOLTAGE CIRCUITS (GREATER THAN 50 VOLTS) ON INTERNATIONAL TRUCKS AND BUSES:**

**WARNING** – To avoid property damage, personal injury, or death, refer to the manufacturer's service information before working on any high voltage equipment. By definition, high voltage circuits and components contain voltage levels that may cause equipment damage, electrical shock, and/or electrocution if handled incorrectly.

Only a trained technician may perform service inside high voltage components. When working around or maintaining high voltage circuits, please seek high voltage training.

**NOTE** – The intent of this section is to provide some basic guidelines when working on or around International vehicles that are equipped with high voltage electrical equipment and circuits. For specific instructions, maintenance, or service information on specific equipment or options, refer to the service manuals for the specified truck models and component(s). It IS NOT the intent of this section to provide detailed service instructions for high voltage equipment and circuits.

**Only a trained technician may perform service inside high voltage components. If working around or maintaining high voltage circuits, please seek high voltage training.**

High voltage systems require the maintainer to be familiar with two types of electrical systems.

**DC (Direct Current)**

Most DC systems on today's trucks use 12volt negative GND. Some systems can store DC electricity in batteries with operating voltages as high as 600 DC volts.

## **AC (Alternating Current)**

The main difference between AC and DC systems is that the voltage levels in DC systems remain constant while the voltage levels in AC systems are constantly changing. When measuring an AC system, it is important to know that the average voltage is zero, and that is why ***A VOLTMETER SET TO DC WILL NOT INDICATE THE PRESENCE OF AN AC VOLTAGE WHEN CONNECTED TO AN AC CIRCUIT!***

High voltage can be lethal. Always refer to the manufacturer of the high voltage component when maintenance or repairs are needed. In most cases, diagnostics and repair are performed after the high voltage circuits are disabled. If working around or maintaining high voltage circuits, please seek high voltage training.

**WARNING** – To avoid property damage, personal injury, or death, circuits must be checked using a voltmeter for the presence of both DC and AC voltages. A voltmeter set to DC will not indicate the presence of an AC voltage when connected to an AC circuit! Contacting an unknown AC or DC voltage may cause equipment damage, electrical shock, and/or electrocution.

### **Understanding High Voltage Equipment and Circuits on International Products:**

Some examples of high voltage equipment that can be encountered on products are as follows:

#### **— Auxiliary Power Units (APUs)**

APUs are basically small diesel-powered generator units that are integrated into the vehicle electrical system. APUs are utilized in combination with inverters and battery chargers. APUs are often set up to automatically start when the electrical management system deems it necessary to maintain battery charge or electrical demand requires it.

**NOTE** - APU high voltage wiring might NOT be marked for easy identification as high voltage.

#### **— Shore Power**

Shore power is a connection from a vehicle to an external 120Volt AC power source. The vehicle is equipped with an exterior receptacle that allows connection to an external “shore” power source.

**NOTE** – High voltage shore power wiring may NOT be marked for easy identification as high voltage.

#### — Inverters

Inverters are electronic devices used to change DC (Direct Current) into AC (Alternating Current). Some inverters contain converters that also convert AC to DC for battery charging or running 12V equipment.

#### — Converters

Converters are electronic devices used to change high voltage DC (Direct Current) to low voltage DC for battery charging.

**NOTE** – High voltage wiring for inverters may NOT be marked for easy identification as high voltage.

#### —Electric Vehicles (EVs)

EVs use high voltage batteries and an electric motor to propel the vehicle. High electrical voltages and currents are present.

**NOTE** – The industry standard for high voltage cables is for the cables to be covered in ORANGE CONDUIT.

If orange conduit is observed on a vehicle, please review the safety precautions for that system.

#### **How to Identify High Voltage Circuits:**

High voltage circuits are not always connected with large wires. The best way to identify high voltage equipment or circuits is to be familiar with the equipment and circuit diagrams as well as to look for high voltage warning labels and orange conduit. **Inspect the vehicle for any equipment or circuits added after the truck was built (owner/operators may add high voltage components such as inverters or APUs).**

All electrical circuits associated with APUs, shore power, inverters, and EVs should be considered high voltage. The standard for high voltage cabling on EVs is orange. APUs, inverters, shore power, and cabin 110/120V outlet wiring may not indicate high voltage by visual inspection (they may not be marked and are NOT orange in color).

#### **Servicing International Products:**

The following steps outline the appropriate method to follow to identify and address any maintenance or service on International products with factory-installed high voltage equipment.

1. Complete related training prior to attempting to identify and service any high voltage system.
2. Review the line-set ticket provided with the vehicle or from the Service Portal and identify all high voltage components. Inspect the vehicle for any equipment or circuits added after the truck was built (owner/operators may add high voltage components such as inverters or APUs that could be live and powering circuits in the vehicle **EVEN WITH THE IGN OFF AND THE BATTERIES DISCONNECTED**).
3. Refer to manufacturer's service publications for identified high voltage components.
4. Physically locate high voltage components on the vehicle and disable them according to manufacturer's instructions (some components may require a waiting period or special procedures to discharge the voltage completely).
5. Use Best Work Practices (see below) when performing work on electrical systems.

### **Best Work Practices:**

**WARNING** – To avoid personal injury or death, permit only trained responsible and capable persons to operate or maintain the equipment. Carelessly operating or neglecting maintenance despite the safe design of any vehicle and its high voltage equipment may result in personal injury or death.

The danger of injury through electrical shock is possible whenever electrical power is present. Most fatal injuries result from high-voltage exposure; however, people can sustain severe injuries from low voltage power if it has a high current flow.

- Be aware of **ALL** high voltage equipment on the vehicle; review line-set/build ticket and the owner and service manuals of high voltage equipment **BEFORE** starting any work.
- When working on this equipment, remain alert at all times. Never work on the equipment when physically or mentally fatigued, and never work alone near high voltage equipment.
- Always stand on an insulated, dry surface when working on any electrical circuit. Do not handle any kind of electrical device while standing in water, while barefoot, or while hands or feet are wet.
- Always work in an adequately illuminated area.
- Always use appropriate protective equipment: insulated gloves, rubber gloves, goggles/face shield, safety shoes, protective clothing, and insulated tools when working on electrical components/circuits of the vehicle.
- Never wear jewelry when working on this equipment. Jewelry can conduct electricity resulting in electric shock or burns and may get caught in moving components causing injury.
- When working on vehicles that have high voltage devices or equipment, use appropriate alerting techniques in plain view to warn people that may be in the general area and to

prevent inadvertent activation of any disabled high voltage circuit(s) during service: safety signs, safety symbols, tags, barricades, cones, etc.

- Keep a fire extinguisher close by at all times. Extinguishers rated “ABCM” by the National Fire Protection Association are appropriate for use on the electrical system. Make sure the extinguisher is properly charged and be familiar with its use. Consult the local fire department with any question pertaining to fire extinguishers.
- Ensure that the high voltage power, high voltage power generating equipment, and high voltage storage devices are disconnected, locked out, or otherwise disabled **BEFORE** working on or around the vehicle, its electrical circuits, or components. Unless disabled, Auxiliary Power Units (APUs) may start at any time without warning; when this occurs, the circuits associated with the APU become energized with potentially lethal high voltage. Some components may require a waiting period or special procedures to discharge the voltage completely.
- Use an appropriate electrical tester and procedures to confirm that the power is disconnected **BEFORE performing any work on or near any high voltage components/circuits.**
- Exercise caution around output circuits even when the input power is off. Parallel power sources and energy storage devices can still be dangerous. Be familiar with the high voltage equipment installed on the vehicle. Some systems contain high voltage condensers that may require time to discharge after power is removed.
- After disconnecting or exposing a high-voltage connector or terminal, insulate it immediately using insulation tape.
- After completion of any electrical work, **BEFORE restoring the power, verify that parts and/ or tools are removed from the work area and that the fasteners are firmly tightened to the specified torque and the connectors are correctly connected.**
- **Voltage can be fatal at levels greater than 60 volts. High voltage can jump a larger air gap than low voltage. If contact is made with high voltage, it may not be possible to simply “let go.”**
- **Towing an EV with its drive wheels on the ground may cause the motor to generate electricity. Consult the operator’s/owner’s manual for proper towing procedures.**
- **If a high voltage fuse or circuit protection device trips, do not re-energize the circuit until it has been determined that the circuit is safe. See manufacturer’s troubleshooting procedures before servicing a high voltage system.**
- Reference OSHA Regulations as necessary and applicable.